

**ELECTRIC AIR COOLER**

**INSTRUCTION MANUAL**



Dear consumer, Please read these instructions carefully before use in order to avoid damage due to incorrect use and to better understand the functions of this product. Please pay particular attention to the safety guide.

If you pass the device on to a third party, these Operating Instructions must also be handed over.

Please keep them for future references.

## IMPORTANT SAFEGUARDS

- ❑ Please read these instructions carefully before use.
- ❑ Keep present instructions for future references.
- ❑ Check that your mains voltage corresponds to that stated on the appliance.
- ❑ Only use the appliance for domestic purposes and household or similar applications such as:
  - staff kitchen areas, in shops, offices and other working environments;
  - by clients in hotels, motels and other residential type environments;
  - Environment type like :
    - Farm Houses • Bed and Breakfast.
- ❑ Only use the appliance in the way indicated in these instructions.
- ❑ Never use this unit near bathtub, shower, wash-hand basins or other containers with water.
- ❑ Never use this apparatus near water projections.
- ❑ Never use this apparatus with the wet hands.
- ❑ If, unfortunately the apparatus is wet, immediately withdraw the cord of the socket-outlet.
- ❑ Inform potential users of these instructions.
- ❑ Never leave the appliance unsupervised when in use.
- ❑ The appliance must be used only for its intended purpose. No responsibility can be taken for any possible damage caused by incorrect use or improper handling.
- ❑ Children and persons with disabilities are not always aware of the danger posed by the use of appliances.
- ❑ This device can be used by children aged 8 years and older and adults, with reduced physical, sensory or mental capabilities or lack of experience and knowledge, if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

- ❑ Cleaning and maintenance must not be made by children without supervision.
- ❑ Keep the appliance and its cord out of reach of children aged less than 8 years of age when it is energized or cooling down.
- ❑ This device is not a toy, do not leave children or people with disabilities to play with.
- ❑ In order to ensure your children's safety, please keep all packaging (plastic bags, boxes, polystyrene etc.) out of their reach.
- ❑ Warning ! Never use without the guards in place. After assembly, do not remove the guards for maintenance purpose or cleaning.
- ❑ Caution ! Do not allow small children to play with the foil :  
**THERE IS A DANGER OF SUFFOCATION !**
- ❑ From time to time check the cord for damages. Never use the appliance if cord or appliance shows any signs of damage.
- ❑ Never immerse the appliance in water or any other liquid for any reason whatsoever.
- ❑ Never place it into the dishwasher.
- ❑ Never use the appliance near hot surfaces.
- ❑ Do not operate the appliance with a damaged cord or plug, or after the appliance has been damaged in any manner. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- ❑ Disconnect the power source cable before any operation of cleaning of maintenance and accessories assembly.
- ❑ Disconnect the power source cable when filling and cleaning
- ❑ Never use the appliance outside and always place it in a dry environment.
- ❑ Never use accessories, which are not recommended by the producer. They could constitute a danger to the user and risk to damage the appliance.
- ❑ Never use any other connector than the one provided.

- ❑ Never move the appliance by pulling the cord. Make sure the cord cannot get caught in any way.
- ❑ Never wind the cord around the appliance and do not bend it
- ❑ Ensure that the power cord does not come into contact with hot parts of this unit.
- ❑ Make sure the appliance has cooled down before cleaning and storing it.
- ❑ The temperature of accessible surfaces may be very high when the appliance is operating. Never touch these parts, of apparatus, to avoid burning itself.
- ❑ Make sure the appliance never comes into contact with flammable materials, such as curtains, cloth, etc...& the power cord and plug do not come in contact with water.
- ❑ Before cleaning, always unplug the appliance from the power supply and let it cool down.
- ❑ This appliance is not intended to be operated by means of an external timer or separate remote-control system.
- ❑ Always place the unit on a flat surface. Ensure, also, not to cover the device and not to put anything on it.
- ❑ Always remove the plug from the wall socket when the appliance is not in use.
- ❑ When using an extension lead always make sure that the entire cable is unwound from the reel. Use solely CE approved extension leads. Input power must be at least 16A, 250V, 3000W.
- ❑ Incorrect operation and improper use can damage the appliance and cause injury to the user.
- ❑ This device, designed for home use, complies with standards relating to this type of product.
- ❑ The appliance must be used and rested on a table or flat & stable surface.
- ❑ The item must not be left unattended when it is connected to main supply.
- ❑ The item is not to be used, if it has been dropped or if there are visible signs of damage.

- This appliance is only intended for household use.
- Regarding filling, cleaning and descaling, please refer to below paragraphs.

## **SPECIFIC SAFETY REQUIRED FOR THIS PRODUCT**

1. Use the fan always set it on a flat surface.
2. Do not carry the device by holding the power cord.
3. Do not insert objects through the protective grill.
4. Do not use the device in a bathroom
6. Do not use near curtains etc.

No warranty will be applied if the appliance is used for other than its intended use.

## **GENERAL INFORMATION**

The symbol "OPEN BOOK" means a recommendation to read important things contained in the record.




The symbol "BIN" crossed out, abbreviation WEEE (Waste of Electrical and Electronic Equipment) means that at the end of life, it should not be discarded with household waste, but filed to the sorting of the locality. Waste recovery can help preserve our environment.



The symbol "CE" is the guarantee of compliance with harmonized European standards, voluntary, reflecting the essential requirements into technical specifications. These standards are not mandatory but are guarantees of compliance with essential requirements.



Can be use in Tropical countries



The symbol ROHS (Restriction of use of some Hazardous Substances) on the Environmental Protection, certifies that for each of the five hazardous substances • Lead • Mercury • (hexavalent) chromium • products for protection against flames PBB and PBDE, the peak concentration is equal to or less than 0.1% of the weight of homogeneous material, and 0.01% for the 6th • cadmium.



The symbol "DOUBLE SQUARE" means a double insulated. A basic insulation and supplementary insulation. This device requires no connection to the mass of a protective conductor grounded. The materials are said : double insulation class II.



The symbol "TRIMAN" indicates that the consumer is invited to dispose the product as part of a separate collection (eg recycling bin, waste, voluntary intake point).



For more information : <http://www.quefairedemesdechets.fr>

## CLEANING AND MAINTENANCE

The fair cooler requires little maintenance.

Do not try to repair it yourself. Bring it back to a qualified service, if necessary.

Always unplug the unit and allow it to cool before cleaning.

Clean the outside of the appliance with a sponge or a slightly damp cloth.

Never immerse the appliance in water or any other liquid!

Never use abrasive products, wire brush or other sharp objects.

The front and back grills can be cleaned with a sponge or a soft, damp cloth. (using a soft brush if necessary).

Use only the original accessories.

Grasp and transport the appliance only by the handle.

- Ensure there is no water tank and it is completely dry before storage.
- Keep away from fire or inflammable objects.
- Do not use in damp rooms (e.g. bathrooms) or in extremely hot places exceeding 40°C.
- Place the fan in its original box or cover the fan to protect it from dust.
- Store in a cool dry place.
- The water tank drawer can be taken out and cleaned to prevent build-up of bacteria. The wet curtain paper can be cleaned using a natural cleaning solution and soft brush. Do not machine wash.

## STORAGE

- Ensure the unit is completely cool and dry.
- Do not wrap the cord around the appliance, as this will cause damage.
- Keep the appliance in a cool, dry place and out of reach from children.

### TO KNOW IT'S UNIT

1. Control panel
2. Temperature display
3. Air outlet
4. Remote Control
5. Water level









## USE

- Unwind the power cord completely.
- Check that the voltage in the country where you are, corresponds to that indicated on the device.
- Connect the appliance to a good electrical outlet, (earthed if the appliance is class I), to avoid any danger.
- Disconnect the power cable from the power supply before performing any maintenance cleaning and accessory fitting.
- Never modify the device.

## CONTROL PANEL



	<b>On/Off button (Marche)</b> Used to turn the air cooler ON and OFF.
	<b>Timer button</b> Press to set up the countdown timer. Each press increases the countdown timer by one hour to 8 hours.
	<b>Mode button</b> Press to choose from ordinary, natural, or sleep mode. The indicator light will turn on next to your selection.
	<b>Swing button (Rotation)</b> Press to turn the oscillation function on and off. When in Swing mode, the air will cycle from side to side horizontally. Press again to turn off.
	<b>Cool button (Frais)</b> Press to turn on air humidification. Press again to turn off. Do not start the cool air humidification function if the water level is lower than the minimum water line as it may cause damage.
	<b>Speed button</b> There are 3 fan speed settings (High/Medium/Low). Press to cycle through, until the desired speed light is on.




## Troubleshooting




Do not attempt to repair or disassemble the unit by yourself, or use an unauthorized repairer. This may invalidate that warranty on the unit or cause serious harm to the repairer.




ISSUE	POSSIBLE REASON	SOLUTION
<b>Not working</b>	<ol style="list-style-type: none"> <li>1. Power cord is disconnected from the power source.</li> <li>2. The power switch is not switched to on.</li> </ol>	<ol style="list-style-type: none"> <li>1. Connect the power cord correctly.</li> <li>2. Turn the unit on.</li> </ol>
<b>Noise</b>	<ol style="list-style-type: none"> <li>1. The air is dusty or the air supply is being restricted.</li> <li>2. The air inlet is being blocked.</li> </ol>	<ol style="list-style-type: none"> <li>1. Take out and clean the air filter.</li> <li>2. Remove anything blocking the air inlet.</li> </ol>
<b>The pump is not working</b>	<ol style="list-style-type: none"> <li>1. The water level in the water tank is below the minimum level required for operation.</li> </ol>	<ol style="list-style-type: none"> <li>1. Fill the water tank to an appropriate level and restart the unit.</li> </ol>

## REMOTE CONTROL

Your air cooler is supplied with a remote control:




	<b>On/Off button (Marche)</b> Used to turn the air cooler ON and OFF.
	<b>Timer button</b> Press to set up the countdown timer. Each press increases the countdown timer by one hour to 8 hours.
	<b>Mode button</b> Press to choose from ordinary, natural, or sleep mode. The indicator light will turn on next to your selection.

	<p><b>Swing button (Rotation)</b> Press to turn the oscillation function on and off. When in Swing mode, the air will cycle from side to side horizontally. Press again to turn off.</p>
	<p><b>Cool button (Frais)</b> Press to turn on air humidification. Press again to turn off. Do not start the cool air humidification function if the water level is lower than the minimum water line as it may cause damage.</p>
	<p><b>Speed button</b> There are 3 fan speed settings (High/Medium/Low). Press to cycle through, until the desired speed light is on.</p>

### Replacing the batteries

The remote control is powered by a Lithium Cell Battery(CR2025). Should the remote become unresponsive, replace the battery following the instruction below:

1. Turn over the remote and press tab A to the right.
2. Slide out the battery tray B.
3. Replace the battery with the same type, ensuring the positive side is facing upwards.



### USING AIR REFRIGERATOR FUNCTION

The air cooler is delivered with 2 ice packs to make a roll. One block in the freezer while the second is used in the tank of the device.

Place the icing blocks in the freezer. After 24H, remove the water tank and place the frozen block in the tank. Add water without exceeding the MAX mark.

The system stores cold and slowly absorbs the warmer recovered water. The cooler system refreshes the water in the tank to make it lower than the environment. So, the tank filled with water and ice allows the air cooler to blow cooler air.

### Ice Crystal Box

1. The ice crystal box is inside the foam packaging at the bottom of the box.
2. Put the appropriate amount of water into the ice crystal box.
3. Tighten the lid and place it into a freezer until completely frozen.
4. Add to Water Tank as required.

5. Two ice crystal boxes have been included so that you can add ice continuously.

#### Adding Water:

1. Pull out the water tank from the back of the machine until two thirds of the tank is exposed.
2. Add only clean tap water to the water tank.
3. Do NOT add water above the 'max' line of the water tank. The water should also NEVER be lower than the 'min' line while using the cool air humidification function.

#### Important notes

- Add water frequently. Add clean water before using. Immediately add water when the water shortage warning comes on.
- Put one ice crystal box in the freezer. Place a pre-frozen one into the water tank for a cool air effect.
- Humidify correctly. The cooling effects are best when adding cool or cold water.
- The water in the tank may appear yellow at the beginning of the humidification process, and will disappear automatically after a short use.
- There may be a light vibration at the start of the humidification process, or when there is a water shortage. Always pay attention to any warning lights.
- Move the machine gently to avoid water spillage.
- Maintain an acceptable water level to avoid damaging the water pump. This can easily be damaged when in 'dry' or 'water shortage' mode.
- Always pay close attention to the water tank line of the water box.

## CAUTION

- Before the first use, check that the unit has been correctly assembled.
- When the appliance is working, do not insert fingers or objects through the grid or into the body of the machine.
- When using a mosquito repellent product, make sure that it is out of reach of children, and if it is accidentally swallowed, seek immediate medical attention.
- Do not place this unit on a sloping floor to prevent tipping, and, do not remove the water tank when the unit is running.
- If the device accidentally spills when it contains water,
  - Unplug the power cord.
  - Remove the water tank

*Check that there is no water accumulated in the unit before reuse.*

When using the unit :

- Do not add disinfectant, vinegar, perfume or essential oils.
- Change the water every 2 days, because the water, in the water tank, can
- easily generate bacteria.
- Clean the tank every 2-3 weeks.

*NOTE : The unit is intended for indoor use.*

## GUARANTEE IN ACCORDANCE WITH REGULATIONS

Before being delivered, all our products are subjected to rigorous checks.

This device is guaranteed for 24 months from the date of purchase of the product by the consumer.

The warranty documents are:

- the invoice and
- the warranty certificate (located on the side or the bottom of the box) stamped and completed.

Without these supporting documents, no free replacement or free repair can be made.

During the warranty period, we take charge, free of charge, for defects in the device or accessories, resulting from a defect in materials or workmanship by repair or replacement.

Services under the legal guarantee do not entail any extension of the guarantee period and do not give the right to a new guarantee.

In the event of a warranty claim, return the complete device to your dealer, in its original packaging, accompanied by proof of purchase.

The breakage of glass or plastic parts is, in all cases, your responsibility.

Wearing parts (for example: motor brushes, hooks, drive belts, spare remote control, spare toothbrushes, saw blades etc.) as well as their cleaning, maintenance or replacement, are not guaranteed. , and are therefore at your expense.

In the event of foreign intervention, the guarantee lapses.

After expiry of the warranty period, repairs can be carried out, against payment, by

a specialist dealer or a repair service.

## SPECIFICATIONS

Power supply	220-240V~ 50-60Hz
Power	110W
Norm	Class II
Maximum fan flow rate	7,14m <sup>3</sup> /min
Fan power input	85,5W
Service value	0,08(m <sup>3</sup> /min)/W
Standby power consumption	0,24 W
Fan sound power level	67,72 dB(A)
Maximum air velocity	3,22 meters/sec
Seasonal electricity consumption	27,63 kWh/a
Measurement standard for services value	COMMISION REGULATION (EU) No206/2012 STR : EU Directive 2009/125/EC EN ISO 5801/2008

Made in PRC

*The characteristics can change without prior notice.*

CAUTION: In order to minimize the risks of electric shock, In the event of breakdown, not to open the case but to call upon a qualified technician for repairs. This apparatus satisfied EC directives, it was controlled according to all the European current directives, like: electromagnetic compatibility (EMC) and low tension (LVD).

This apparatus was designed and manufactured in respect of the last safety regulations and technical specifications.

**Imported by Sotech International  
" LE PERIPOLE "**

**33, Avenue du Marechal de Lattre de Tassigny  
94120 Fontenay sous-bois - France**

The symbol " CMIM " is the guarantee of compliance with optional harmonized Moroccan Standards, which reflect the essential requirements in terms of technical specifications. These standards are not mandatory but ensuring compliance with the essential requirements.

