


User Manual

Wake Up Clock-Ver1.0



Thank you for purchasing this product. To ensure properly use and trouble-free operation, please read this manual carefully and store it in a safe place for future reference.

1


PACKAGE CONTENTS

- 1 × Wake Up Light
- 1 × USB Power Cable
- 1 × Power Adapters
- 1 × User Manual


TECHNICAL SPECIFICATIONS

- Input voltage: 5V DC
- Input current: 1000mA
- Standby power : <0.5W

PRODUCT OVERVIEW



2



OPERATING INSTRUCTIONS

1. Power On/Off

Press and hold the button to on/off the fall asleep mode.

Short press the button to on/off the night light . Short press the button to on/off the sounds.

2. Adjusting Night Light Brightness and Color Light

Press and hold the button to increase the brightness level and the button to decrease the brightness level among all 20 brightness level.

Short press the and the button to switch among all 12 colors light and the breathing light mode in sequence .

Note: Breathing light brightness cannot be adjusted. 3

3

3. Adjusting Volume and Switching Sounds

Press and hold the button to decrease the volume and button to increase the volume. Short press and buttons to switch among all the 25 sounds in sequence.


Track list:

- | | |
|-----------------------|------------------------------|
| 1. Brown Noise | 2. Pink Noise |
| 3. Soft Fan | 4. Rain on Yard |
| 5. Heavy Rain | 6. Rain on Window |
| 7. Stream in the Cave | 8. Brook |
| 9. River | 10. Gentle Sea Wave |
| 11. Mighty Sea Wave | 12. Little Sea Wave |
| 13. Singing Birds | 14. Campfire1 |
| 15. Campfire2 | 16. Campfire3 |
| 17. Train | 18. Piano |
| 19. Brahms Lullabies | 20. Alpha Wave with Dripping |
| 21. Star Dust | 22. Meditation |
| 23. Edelweiss | 24. Mozart Lullaby |
| 25. Subote Lullaby | |

4

4. Adjusting Sound Timer and Night Light Timer

Press and hold the button to set the timer. There are a total of 5 timer light indicators which stand for sound and night light continuously play, 1-hour timer, 2-hour timer, 3-hour timer and 4-hour timer respectively.



5. Adjusting Time

Press and hold the button to setting time. When the time digits on the screen start to blink, short press the button to switch from the hour setting. And short press the button and the button will allow you to adjust the time and switch the 12/24 hour format.

Note: When the AM/PM light indicator is on, it means the time is in 12-hour format.

5

6. Adjusting Dual Alarm Clock (Sunrise Simulation)

Short press the button or button can separately turn on / off the current clock.

Press and hold the Button or the button can separately display the current alarm clock information and start adjusting the alarm clock value.

When the digital icon on the screen is blinking, you can short press the button or the button to switch to the settings of the alarm clock time, ringtone, volume, light brightness and sunrise time, and adjust their values by short pressing the button and the button.

Note:

- 1.The setting information will be saved after you finish all settings regulations or you can press the button or the button for 2 seconds to save proactively .
- 2.When the set alarm clock time arrives, the alarm clock will ring gradually within a minute.
3. The lamp will slowly light up before the alarm clock time, which depends on how you adjust sunrise setting.
4. Built in 29 sounds, which can be selected as alarm clock ringtones (7 of which are classic alarm clock ringtones)

6

7. Adjusting Fall Asleep (Sunset Simulation)

Press and hold the button to on/off the fall asleep mode.

Press and hold the button to setting the fall asleep mode.

When the digital icon on the screen is blinking, you can short press the button to switch to the settings of sound tracks, volume and fall asleep time (10 to 90 minutes).

Short press the button and the button will allow you to adjust their value. The light and sound will be cut off automatically right after the set time ends.

NOTE:

The setting information will be saved after you finish all setting regulations or you can press and hold the button for 2 seconds to save proactively.

8. Adjusting Screen Display Brightness

Short press the button to adjust the brightness of screen display, there are four brightness options, the order of brightness changes is: Off - Low brightness - Medium brightness - High brightness.

7

9. Adjusting SNOOZE mode

When the alarm sounds, short press the button, the alarm will continue to ring after 10 minutes.

When the alarm sounds, press and hold the button, or short press the button or the button can separately turn off this time the alarm clock.

FEATURES

1. White noise machine (Built with white noise \ fan sounds \ nature sounds \ ambient \ Piano \ Meditation sounds for your choices.)
2. Night light (12 Colorful, include breathing light)
3. Sunrise Simulation
4. Sunset Simulation
5. Dual Alarm Clocks
6. Adjustable LED Time Display Brightness

WARRANTY INFORMATION

If you have any product question , or you have any product issues, please contact our e-mail:

Your name: _____ Order number: _____
E-mail: _____ Phone: _____ 8

8

TROUBLE SHOOTING


If the unit has a problem, try to follow the instructions below to solve it.

Problems	Possible causes	Solutions
The clock time indicator is off	Brightness of screen display is off	Short press the button to adjust brightness
	Improper power adapter is used	Make sure the original adapter is used.
Some button is not available	In alarm clock setting mode	Press and hold the button to exit alarm clock setting mode
	In time setting mode	Press and hold the button to exit time setting mode
No sound, but the Continuously Play/Timer light indicators is on	The sound is adjusted too low.	Press the volume "+" button to increase the volume
	Handle standby status	unplug the adapter , and plug in again 9

9

Wake up your good life

Tip 1: Button Quick Guide



Tip 2: Adjusting Continuously Play

When the indicator light is white, it means that the sound and night light are continuously playing.

10