

Handleiding

Instruction Manual



The Wooden Balance Bike User Guide

Thank you for choosing the Wooden Balance Bike!

Safety First:

Please read this manual fully to ensure you have a fun and safe time with your bike.

- Parent or adult supervision is recommended at all times. You must ensure your child is confident and capable of stopping before allowing them anywhere near roads/cars, and should develop an awareness of road rules and safety. When your child is using the Wooden bike on a public footpath, please be aware of driveways and the danger of reversing cars.
- These bikes are designed to allow young children to learn to get their balance on a bike, they should not be used on public roads.
- Wearing a helmet is strongly advised. This is no different to any other bicycle and safety must come first.
- The Wooden Balance Bikes are designed for children aged between 1-3 years.
- This product should be assembled by an adult. Please ensure all fittings are tight and everything is correctly assembled before use.
- The Wooden Balance Bike is designed to take only one child (weighing less than 25kg) at a time.


Assembly:

- Please follow the assembly instructions as shown. Ensure you do not over-tighten any screws.
- The rear wheel bolt assembly consists of a bronze bolt and nut, 2 x stainless steel spacers and 2 x white nylon washers. Your bike will come with the bolt in place and the spacers and washers in place. The image shows the order in which these should be placed when you attach the wheel.
- The Wooden Balance Bike comes with the seat set for a beginner/young rider, in the lowest of 3 possible positions. The seat position should be adjusted according to your child's height.
- Please keep your bike out of the rain and damp.
- Clean your Wooden Bike with a damp cloth but do not use any chemical cleaners.



Made in China

1



2

