## **AovoPro**

# **Electric Scooter Manual**

# **Manual d'Utilisation**

# **Scooter Electrico Manual**

1. APP download & Functions	
2. Téléchargement de l'application et fonctions	05
3.APP descargar y funciones	07
4. The Device& Accessories	
5.Assembling the device	11
6.Charge the scooter	
7.Driving Instructions	
8. Safety Recommendations	
9. Folding & Transportation	
10. Daily Maintenance and Storage	
11. Model Specifications	
12. Presence of toxic and harmful substances	
13.Warranty	

## 1. AovoPro APP download & Functions

1.Please search aovopro from APPstore or google play to download and install ontocellphone, you can also scan the right QR code or following link to download the aovopro app:https://apps.apple.com/app/aovopro/ id1484658812

andriod:https://play.google.com/store/apps/details?id =com.zydtech.aovopro

2.After app installed , please press the switch on/off button for 1second to turn on scooter.

3.Open the cellphone bluetooth ,and open the aovopro app,the scooter is automatically connected the app,then you can use the apptoswitch on/off the light&scooter, changespeed,set up cruise control or lock scooter.

4.If you do not want to use the app, you can also use the button on the display to operate the scooter .

Press for 1 second to switch on scooter, press for 3 seconds to turn off; Pres one time to turn on/off light;

Press twice quickly to change the speed gear APP function



Details	8 X 8 500 8
Dotails	
Battery	37%
Sceed	Okraft
Voltage	35.8V
Current	0.CA
input power	0.0W
Controller temperature	22*C
Subtotal	Dicm
Total mileage	16km
APP version number	








AovoPro

#### Scooter display function



## **2. Téléchargement de l'application et fonctions**

1.Veuillez rechercher aovopro sur APPstore ou Google Play. pour télécharger et installer sur un téléphone portable, vous pouvez également scannez le code QR ou le lien suivant pour le télécharger l'application aovopro: https: //apps.apple.com /app/aovopro/id1484658812

andriod: https: //play.google.com/store/apps/details?id=com .zydtech.aovopro

2.Une fois l'application installée, veuillez appuyer sur l'interrupteur marche / arrêtbouton pendant 3 seco-ndes pour allumer le scooter.

3.Ouvrez le bluetooth du téléphone portable et ouvrez le aovopro l'application, le scooter est automatiquement connecté à l'application, alors vous pouvez utiliser l'app pour allumer / éteindre la lumière et scooter, changer de

vitesse, régler le régulateur de vitesse ou le verrouiller scooter. 4.Si vous ne souhaitez pas utiliser l'application, vous pouvez

utilisez également le bouton sur l'écran pour faire fonctionner le scooter. Appuyez pendant 1 seconde pour allumer le scooter, appuyez pendant 3 secondes pour éteindre;

Pressez une fois pour allumer / éteindre la lumière;

Appuyez rapidement deux fois pour changer le levier de vitesse Fonction APP








AovoPro

#### Fonction d'affichage du scooter



vitesse vitesse, vide est basse vitesse le vert est la vitesse moyenne accélérateur


bouton allumer / éteindre



- vitesse vitesse, le rouge est haute vitesse
- vitesse en temps réel
- capacité de la batterie



activer le régulateur de vitesse



scooter verrouillé

## 3. APP descargar y funciones

1.Busque aovopro en Appstore o Google playpara descargar e instalar en su celular, también puedeescanear el código QR o el siguiente enlace para descargarla aplicación aovopro IOS: https://apps.apple.com/app/ aovopro/id1484658812;

Andriod: https://play.google.com/store/apps/details? id=com.zydtech.aovopro

2. Después de instalar la aplicación, presione el interruptor de encendido/apagado botón durante 3 segundos para encender el patinete eléctrico.

3.Abra el bluetooth del teléfono celular y abra el aovopro aplicación, el scooter se conecta automáticamente a la App,entonces puedes usarla para encender/apagar la luz yscooter, cambiar la velocidad, configurar el control de crucero o bloquearscooter.

4.Si no desea utilizar la aplicación, puedetambién usar el botón en la pantalla para operar el scooter.

Presione durante 1 segundo para encender el scooter, presione durante 3 segundos para apagar;

Presine una vez para encender/apagar la luz;

Presione dos veces rápid amente para cambiar la palanca de velocidad. Función de la APLICACIÓN

	scooter conectado	in	formación del		establece	r límite de	velocidad
tiempo re velocidad bloquear scooter	<b>0.0</b>	igero Incendido Ipagado	Current Irpst power	37% 0%% 358V 0CA 0.0W	Cooleration Accoleration Accole	•	5 5 250 >
scooter conectado apagado Velocid <del>ad</del> nivel	Contraction Contract (S)	crucero encendido apagado scooter informacion	Controller temperature Skototal Total mileage APP version number	224C Dicim 18km 1.1.1	Cel	Speed limit value	Cm





IOS

AovoP

#### Función de visualización de scooter



freno

engranaje de velocidad, verde es velocidad media

acelerador

botón de encendido / apagado




engranaje de velocidad, en blanco es de baja velocidad el rojo es de alta velocidad

- el l'ulo es de alta velocidat
- velocidad en tiempo real
  - capacidad de la batería



encienda el control de crucero



## 4. The Device & Accessory



#### Accessory






\_\_\_\_\_

\_\_\_\_\_





\_\_\_\_\_



## **5.** Assembling the device

1).fix the steering rod and open the parking bridge



Using hex wrench in the packing box to tighten the screws on handle bar



2).Set handle bars vertical;



4. Testing the power switch after finish assembling



## 6.Charge the scooter









Open the cover


connect the charger close the cover

## **7.Driving instruction**

Please wear helmet and


knee pads when practice

1 .Power on and check the battery led light





2,.Stand on pedal with one leg, hit the ground with the other leg



3,.Step on the other leg when the scooter is moving, then press the accelerate button (only accelerate when the scooter speed is beyond 5km/h)

4.loose the accelerate button when slow down. Energy recovery systems will open itself to slow down. Press the left disc brake tightly if want to brake urgently.

5.lean your body left slightly to turn left, lean your body right slightly to turn right. And turn the handlebar slowly



## 8. Safety Instructions

It is not recommended driving on the rain

It is recommend to slightly bend knees to better adjust to a rough road.If you are travelling on a rough road,stick to low speed (5-10km/h)









Entering into any room, elevator, etc. Be careful not be injured by a door frame.

Please not add speed when descending a hill







While walking with a scooter,



When driving it is recommended to go around various obstacles on a road




When driving is forbidden to place one footon the running board






Please do not hang backpacks and other heavy objects on handle bars ground






## Preventing dangerous driving

It is forbidden to leave a scooter on a scooter wheel at high roadway for motor vehicles or ride in at a high speed




It is forbidden to drive through puddles, to which exceeds depth of 2cm.


It is forbidden to sharply turn a a residential area with a large flow of passers-by




Never rider a scooter more than or one person, hold a child in your arms.













Do not driving leaving your hands

Do not riding electric scooter up, down steps or jump over obstacles

## 9.Satety Recommendations

1) Electric scooter - it is only a device for entertainment, not vehicle.But once you driving to public area, the electric scooter brings certian risks for your safety .For the sake of your safety and others safety, you must strictly follow the instructions, outlined in this driving manual.

2) You should understand that is you ride a scooter in a public place , you must comply with all recommendations for safety. Also do not forget that there is a possiblity of collision, due to violation of pedestrians or vehicles traffic rules , there is also a risk of injury , due to improper operation of the unit. As in other types of vehicles, the higher a speed of electric scooter, the greater a braking distance. On some smooth road emergency braking may cause skidding of scooter, loss of balance and even fall. Therefore, during moving of scooter you need to be vigilant, to adhere to an appropriate speed , keep a safe distance from pedestrians and / or with other vehicles . Riding on unfamiliar terrain, keep vigilance and appropriate speed.


3) While riding scooter , respect rights of pedestrians . Do not scare them, especially children. Reduce speed, passing by them. If you are moving in the same direction with pedestrians, try to stick to the left side as much as possible (for right-hand traffic countries ). If you are moving in the opposite direction, stick to the right and slow down.

4) Please strictly following your country road rules to driving, and also strictly abide by rules , set out in the instructions and safety recommendations. Violation of the above rules may result financial expenses, personal injury, occurrence of traffic accidents, legal disputes, conflict and other unpleasant situations. Our company does not bear any direct or joint and serveral liability.

5) To avoid personal injury , do not loan electric scooter to others whom do not know how to drive. Please spend a training before you transfer your scooter to friends, as well as teach he(her)must be wear the proper safety gear .

6) Please do inspect scooter carefully before each use. If you find shattered parts , battery life has decreased obviously, tires leak air or there are signs of excessive wear, uncharacteristic sounds when turning or other abnormal symptoms, please discontinue use of the scooter immediately , don't drive it reluctantly.

### 9.Fold and Transportation



Make sure scooter be off, hold the front pole, loosen a lock lever and lower a steering rack. Adding a steering rack in a horizontal position and secure it by inserting a hook through a special ring, which is located on the rear wheel mudguard. To Assemble the scooter, disconnect a steering rack lock from a hook of a mudguard, and then lift it into a vertical position and lock a lever.

### Transportation

You can transfer folded scooter with one hand Vous pouvez déplacer le trottinette pliage avec seule main





## **10.** Daily Maintenance and Storage

If you find any stains on electric scooter housing, use a soft, damp cloth to wipe the vehicle; You can use toothpaste and a toothbrush to clean the scooter from stains, and then wipe it clean with a damp cloth. If you find scratched on parts, made of plastic, use sandpaper or other grinding materials for their polishing.

Warning : Do not use alcohol, petrol,kerosene or other corrosive solutions , volatile chemical solvents to clean the vehicle. Otherwise, it will cause serious damage to the scooter body and can disrupt a structure of internal elements. Do not wash electric scooter under a strong pressure of the water, make sure the scooter in the off status. In addition, after charging of the vehicle, it is necessary to insert a plug back to a charging connector, otherwise you may get an electric shock , or may have serious water damage cause from water falling into this hole, may have serious water damage.

If you do not use the scooter ,store it in a dry ,cool place and do not leave the unit for a long time on the street.Leaving the device under the sun/in extremely high temperature/over-low temperature can cause rapid aging of an outer body and wheels of Electric Scooter or reduce battery life.

### Maintenance of Electric Scooter battery

1)Do not use batteries from other brands in order to avoid a dangerous situation;

2)Do not open or disassemble the battery to prevent electric shock. Avoid contact with metal objects to prevent an occurrence of a short circuit. Otherwise, the battery may have malfunction or can injure the user;

3)It is recommended to use an AC adapter, that comes in original configuration of

the device, to prevent an occurrence of an accident or fire of the vehicle;

4) Improper disposal of used batteries and accumulators is the cause of severe environmental pollution.Please,dispose of batteries in accordance with local laws.Please do not dispose of batteries together with food waste.Protecting the environment together!

5)After each use of the device, charge the battery to prolong its service life.

Do not store the scooter battery in rooms with temperatures, that exceed  $50^{\circ}$ Cor -  $20^{\circ}$ C(for example, do not leave the battery of Electric Scooter and other batteries in cars in summer time on the hot sun), do not leave the battery near fire. As a result of these actions may deteriorate the battery, overheating and can even cause inflammation.

If within 30 days the scooter is not used, charge the battery and keep the device in a cool, dry place. Every 60 days you need to charge the battery, otherwise there is the likelihood of its failure, which is not subject to warranty services.

Avoid a full discharge of the device, it will to extend battery life. When using the device at normal room temperature, the battery will be able to ride much greater distance and its performance will be better; but if you use the scooter at temperatures below 0C, vehicle performance and permeability decrease.


At-20C a traveled distance is less, than the scooter in the normal conditions of half or even less. If a temperature rises, a traveled distance by the vehicle will also increase. You can check remaining distance in the Application.

Note: A fully charge scooter runs about 120-180 days of standby time. The battery has a smart chip, that stores information about its charging-discharging. If you are not charging the battery for a long time, it can cause serious damage, for which it is impossible to charge the device again. This kind of damage is not included in free warranty service. (Caution: Do not disassemble the device by unauthorized

people, as there is a risk of electric shock or serious injury as result of a short circuit.


#### Adjusting a brake disc

If a brake is very tight:using M5 hex wrench and scroll counterclockwise screws of brake disc tensioner pulley, slightly shorten a length of a tail brake cable, then tighten a tensioner pulley. If you think that brake is very free, loosen a tension pulley, pull a brake cable to slightly increase a length of its tail. Tighten a tension pulley.




#### Adjusting a handle bars

Staggering of steering rack: using a M5 hex wrench, tighten two screws near the folding mechanism.



#### Using a connecting pipe to pump wheels

If a rear wheel of Electric Scooter deflated, connect a connecting pipe to a wheel nipple to pump it .First, remove the a cap of pin, then tighten a fitting, and then you start to pump a wheel.



## **11. Model Specifications**

Operating parameters	Name	Ew6parameters	
Dimensions	Length x Width x Height	106 x 42 x 48	
	Folded:Length x Width x Height(cm)	106 x 42 x48	
Weight	Gross weight	12.5kg	
Conditions	Max load	120	
	Agee	16-50	
	Height(cm)	120-200	
Main Parameters	Max speed(km/h)	31	
	Possibility in average Condition [2](km)	25-35	
	Maximum slope(%)	20	
	Suitable area	Solid road surface, surface to overtime high less than 1cm pools no more than	e,obstacles ,a depth of
	Operating temperature range(°C)	-10-40	
	Temperature of storage(°C)	-20-45	
	Waterproof level		
Battery Parameters	Rated voltages(VDC)	36B	
	Max voltage of charging(VDC)	42B	

	Rated power(Wh)	280-378		
	Smart battery management system		icient	voltage,short
	t	circuit,auto		sleep/wake
		up,overheati	-	
		protection,co	ontrol	of battery
Motor Parameters	Rated power(W)			
		350		
	Max power(w)	350		
Adaptor				
power	Rated power(W)	71		
Parameters	Input Rated voltage(VAC)	100-240B		
	Output Rated voltage(VDC)	42V		
	Rated current(A)	1.7		
	Certificate	CE,RoHs		
	Charging time(h)	Est . 3.5	Est	. 5

### 12. Presence of toxic and harmful substances

Toxic and harmful substances elements   Name						
	Pb	Hg	Cd	Cr6+	PBB	PBDE
Power Adaptor	X	0	0	0	0	0
Battery	Х	0	0	0		0
Connecti ng pipe	X	0	0	0		0
Charging Port	Х	0	0	0		0
Indicators	Х	0	0	Х	Х	Х
Circuit Board	Х	0	0	Х	Х	Х
Motor	Х	0	0	Х	0	0
Housing	Х	0	0	0	0	0

Date provided in accordance with provisions of SJ/T 11364.

O:toxic and harmful substances in all components of the device are contained in an amount below the limit value, according to standard GB/T 26572-2011.

X:presence of toxic and hazardous substances at least one of components of the device in an amount,that exceeds the threshold,according to GB/T 26572-2011

### 13. Warranty

Warranty service is carried out in accordance with the law on  $\langle consumer rights \rangle$  and the  $\langle Law$  on the quality of products. The warranty service includes:

Recommendation: use the packaging for safe transport of the device.We recommend keeping the original packaging within 15 days after receipt of goods.

Name	Information on warranty maintainance	Term
Main Unit	hub motor, controller, steering	1 year
Accessories	Battery, power supply,	6 Months

#### **II.** Warranty terms

Caution:

Hex wrench, connecting pipe and other consumable component parts have no warranty.

#### III. Non - warranty regulations

1. Authorized maintenance, misuse, collision, negligence, abuse, intake, accident. Improper use of non-product accessories, or tear up the modified label, anticounterfeit mark.

2. The warranty period has expired;

3.Damage, caused by force majeure;

4.Failures, which do not correspond to the 《List of faults》 of EcoRider service center;

5.A failure of the device or its components from the 《Fault list》, which arose in connection with the human factor, and which interfere with normal operation. 6.Failures, that have arisen in connection with the human factors (including, but not limited to, excessive wetting device, puncture, drop, scratch and damage an outer casing, which have arisen as a result of normal use of goods)

7. If this product is used for commercial purposes, all warranty conditions are not maintained.

Name of fault		
Incorrect motor operation		
Problems with operation of the controller		
	Problems with charger	
	Problems with battery	
Electric Scooter	In use, the occurrence of cracks, deformation, etc	

#### **IV. List of faults**