



aerorest<sup>®</sup>

# Cloud Top

USER MANUAL



Thank you for purchasing a AeroRest Cloud Top airbed. To ensure safety and avoid any property damage, please read this manual carefully and use it as indicated. Failure to comply with the instructions and warnings provided herein may result in inaccurate results and/or damage to the product itself. Save this manual for future reference.

**Warning: RISK OF SUFFOCATION**

- Infants have suffocated on an inflatable mattress. Never place an infant 15 months or younger on an inflatable mattress.
- When used by children over 15 months, provide at least a shoulder-width space between mattress and walls, dressers, or vertical objects to avoid entrapment.
- Always keep mattress fully inflated when in use.

**WARNING**

To reduce the risk of burns, fire, electric shock or injury:

- Always unplug the air mattress when not in use.
- Close supervision is necessary when this furnishing is used by, or near children, or people with limited mobility.
- This air mattress is only to be used for its intended use as described in this manual.
- DO NOT operate this device if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it is wet.
- Keep the power cord away from heated surfaces.
- DO NOT block the air openings while the device is in operation.
- Always keep air openings free of lint, hair, and other small objects. Never drop or insert objects into any of the openings.
- DO NOT use the air mattress outdoors or in damp areas, this product is for household use only.
- DO NOT operate this device where aerosol(spray) products are being used or where oxygen is being administered.
- DO NOT use the air mattress to support video equipment such as televisions or computer monitors.
- DO NOT use near people using or wearing medical devices.
- Keep away from sharp objects that may damage the product. Do not operate with any sharp tools or gadgets around when the mattress is being used.
- Infants have suffocated on inflatable mattresses. Never place infant aged birth to 15 months or younger to sleep on this inflatable air mattress. Infants can suffocate on an underinflated or deflated mattress, on bedding, by co-sleeping with another person, and by entrapment between the mattress and bed frame or between the mattress and a vertical surface.
- Children can be entrapped between the inflatable mattress and an adjacent vertical surface. Provide at least a shoulder width space between the inflatable mattress and adjacent vertical surfaces such as walls, dressers, or other objects.

- 15. Always keep the inflatable mattress fully inflated when in use.
- 16. DO NOT open the air pump casing for any reason.
- 17. DO NOT use on surfaces where heat may cause a problem.
- 18. A fire may occur if this device touches or is covered by flammable materials including curtains, draperies, cardboard, plastics etc., while in operation.
- 19. DO NOT operate the pump in enclosed spaces that are not well-ventilated. Always ensure there is at least 2ft of clearance from any wall or object while the pump is in operation.
- 20. DO NOT operate the pump in the presence of explosive and/or flammable fumes.
- 21. DO NOT place any part of the pump or cord in or under water or other liquid.
- 22. DO NOT exceed the weight limit for this device: 200kg (440lb) (Single Size) and 295kg (650lb) (Queen Size).

**CAUTION:** This device is operated with an electrical air pump that is thermally protected. The pump does not contain parts that can be repaired or serviced. Opening the pump casing may expose to the risk of electric shock. If you have any issues with the electrical pump upon arrival, please contact our helpful customer service team immediately.


**Attention: PVC Material**

The PVC Material will naturally stretch and expand during use. After being inflated and/or having been slept on for several days, the air mattress may lose some of its initial firmness due to the PVC expanding. This is normal and is not the result of air leak. Add air to the mattress to regain your desire firmness level using the built-in air pump.

**Using the Product**

**1. Product Introduction**

- 1. Air Mattress
- 2. Power Cord
- 3. Power Cord Compartment
- 4. Control Dial
- 5. Stoma
- 6. Manual Inflation/Deflation Valve



**2. What's in the box**

- 1 x Air Mattress
- 2 x Patch
- 1 x Carry Bag
- 1 x User Manual


### 3. Specification

Model No.	Single	Queen
Dimensions	210x99x51cm 83x39x20in	210x152x51cm 83x60x20in
Max Weight Capacity	200kg (440lb)	295kg (650lb)
Voltage	220-240V	220-240V
Rated Power	150W	150W

### 4. Operation

#### Before you start

1. Remove the air mattress from its packaging and unfold it so that the sheet side with zipper is facing up.
2. Open the power cord compartment and connect the power cord to an electrical outlet.




3. Push the valve inside tightly, in case of leaking from valve.



#### Inflate

1. Turn the control dial clockwise to "Inflate" the air mattress.
2. Turn the control dial back to "off" when the mattress has reached the desired firmness. Make sure the control dial is aligned with the "off" arrow.
3. Lie on the air mattress to test the firmness.
4. Adjust the firmness by either continuing to inflate the air mattress or turn the control dial to "Deflate" to let some air out.
5. Unplug the power cord and store it in the power cord compartment.




## Deflate


1. Plug in the power cord and turn the control dial counterclockwise to “Deflate” the air mattress.
2. Allow the air mattress to completely deflate. Unplug the power cord and place it back into the storage compartment.
3. Lay mattress sheet side with zipper up and fold the mattress , then roll up the mattress to release any remaining air.

## Manual Inflation/Deflation

1. Open the cover of the valve and the upper layer would be revealed (as see in the pic). Connect an air pump or hose (Purchased by yourself) to the mattress. Inflate the mattress to the desired firmness level and disconnect the air pump.



2. To deflate the mattress, fully open the cover manual inflation/deflation valve to release all of the air from the mattress
3. Close the cover.










## 4. Folding & Storing

- a. Deflate the air mattress completely. Unplug the power cord and place it back into the power cord compartment.
- b. Fold the mattress with the sheet side with zipper facing up, then roll up the mattress to release the remaining air. Place the air mattress into the provided storage bag and store it in a cool, dry place.


**Note:**

- a. Make sure the floor is clean before unfolding the air mattress.
- b. Keep the air mattress away from sharp objects that may damage it.




## How to Locate the Leak

In rare cases in which there is a leak requiring repair, you must find the source of the leak first. There are 3 ways to find out the source of the leak. Before inspecting the source of the leak, make sure the mattress is fully inflated.




### Method 1: Locate the leak by listening.

Place your ear 2-3in away from the mattress. Press upon the fully-inflated air mattress until you find the source of the hissing sound.



### Method 2: Locate the leak with your wet palm.

Run your wet palm along the entire surface of the mattress. The air escaping from the mattress will quickly evaporate the water, making your palm feel cool.




### Method 3: Locate the leak with soapy water.

Add a little liquid dish soap to a spray bottle filled with warm water. Mix them thoroughly to ensure that you can get an even amount of soap across the whole mattress. Escaping air will cause bubbles to form on the surface.

### Tips:

- Spray the surface of the mattress systematically. Start with the seams, followed by the rest of the fabric.
- Wipe the soap away with a clean sponge/cloth and dry the mattress when you are done.

**Mark the leak with a permanent marker once you locate it.**



## How to Repair the Product

### Step 1


Completely deflate the mattress and lay it flat on the ground.

### Step 2


Clean and dry the area around the leak. Gently press the leak center with your thumb to flatten any wrinkles, then apply the patch to the leaking area and press firmly.

### Step 3


Press the patch with a heavy object and check if the leak is repaired in 2-4 hours.



Step 1



Step 2



Step 3

## Important Tips

1. When opening the package, there may be an odor from the product due to its PVC material. Please keep it in a ventilated place and the odor will dissipate soon.
2. When inflating the air mattress for the first time, it is better to let the mattress rest for 8-12 hours so that the seams can buffer.
3. It is normal for the air mattress to lose a small amount of air after it is fully inflated.
4. If you use the air mattress for more than one night, inflate it for 10-15s each day to maintain its firmness.
5. Always make sure the control dial is in the "OFF" position after inflating.
6. It is not recommended to run the air pump for more than 5 minutes. After 5 minutes of continuous use, the air pump will start to generate heat. When it does, allow the air pump to cool down for 30 minutes before re-using it.



## Maintenance and Cleaning

1. Fold the air mattress gently to prevent sharp bends, corners and creases that may cause damage.
2. Make sure the mattress is clean and dry before storing.
3. Store the mattress in a cool, dry place.
4. Use soapy water to clean the surface of the mattress. DO NOT use any chemicals, solvents or harsh detergents.
5. No air pump maintenance is required.
6. To repair punctures in the air mattress, use only common PVC repair glue and patches.
7. DO NOT use flammable aerosols on the surface of the air mattress.

## Customer Service

We have an award-winning customer service team that guarantees hassle-free solutions to any issue you might have within 24 hours.

✉ Email:

☎ Tel:

**Monday-Friday 9:00AM-4:30PM**