

## PLAIN RICE COOKING

### 1 Measure the plain rice volume

Use the measuring cup provided. Each cup of uncooked plain rice normally can give about 2 bowls of cooked rice. Do not cook rice outside the range indicated inside the pot. The rice cooker cannot perform the normal rice cooking function outside the specified range.

### 2 Wash the rice

Wash the rice gently and thoroughly. We advise you to use a separate container during washing to avoid damaging the non-stick coating of the inner pot.

### 3 Add water according to the marking inside the pot

Pour the pre-washed rice into the inner pot. Add water according to the marking indicated inside the pot that is corresponded to the cups of plain rice that are poured, ( Fig.1 ) then smooth the rice surface. The level marked inside the pot is just an indication, you can always adjust the water level for different types of rice and your own preference.

### 4 Check to ensure the pot is in good contact


Before connecting the power, ensure the outside of the inner pot is dry and clean and that no foreign object is on the heating plate or the magnetic switch. Close the lid firmly until it gives a "click" sound to avoid improper rice cooking.

### 5 Connect to the main power supply

Connect the unit to the mains. The light of the "COOK" mode will be on.

### 6 Press the Control Button to start cooking

To start the rice cooking process, press down the control button and the light of the "COOK" mode will stay on to indicate that rice cooking is in progress ( Fig.2 ).

 If you do not press down the control button, after a few minutes, the light of the "COOK" mode will go off and the light of the "WARM" mode will be on automatically to protect the normal function of the rice cooker.

### 7 Keep warm

When the cooking process is finished, the light of the "COOK" mode will go off and the light of "WARM" mode will be on automatically.

### 8 Stir the rice

For best results, open the lid after the light of the "WARM" mode goes on and stir the rice to allow excessive water to escape. Then close the lid firmly to continue the keep warm function ( Fig.4 ).

### 9 Power off

To stop the keep warm function, simply unplug the unit from the mains.

## HOW TO CLEAN

### The inner pot, steam tray and inner lid:

1. Before cleaning, unplug the unit from the mains and let it cool down completely.
2. Remove and clean the inner lid, the inner pot, steam tray and dew collector after every use. Soak them in lukewarm water.
3. Wash with a sponge or a soft cloth.
4. Do not use any abrasive cleansers, steel wool or metal utensils to clean the non-stick inner pot as these will damage the non-stick coating.

### The main body and outer lid:

1. Before cleaning, unplug the unit from the mains and let it cool down completely.
2. Use only a damp cloth to wipe the outside of the unit. DO NOT immerse the main body in water.



## MULTI FUNCTION COOKER


MODEL NO.: HG-8004

Voltage: 220-240V a.c. 50-60Hz Power: 700 WATTS






The Manufacturer will not be liable for any damages or injuries resulting from failure to comply and adhere to the safety warning and guidelines in this manual.

## PARTS IDENTIFICATION



## ILLUSTRATION



## ACCESSORIES





Measuring Cup



Rice Scoop



Steam Tray



## PRECAUTION

- Please read this instruction manual thoroughly and carefully before you start operating the unit to ensure safe and reliable performance.
- Before use, check if the voltage indicated underneath the rice cooker corresponds to the main voltage at your home.
- Before placing the inner pot into the rice cooker, make sure that the heating plate and the magnetic switch are clean and dry.
- Do not switch on when the main body is empty.
- Do not obstruct the steam vent hole with any article, e.g. a piece of cloth.
- Do not place the inner pot directly over open flame for cooking.
- During operation (i.e. cook or keep warm function), avoid touching hot parts: outer lid, inner pot, inner lid, steam tray and especially the steam vent hole.
- This rice cooker can only be used for cooking plain rice and keeping warm, and is NOT suitable for other purposes such as making soup, boiling water, cooking congee or vegetables. Otherwise, water may overflow which affects the safe use of rice cooker.
- For best rice quality, it is recommended to keep rice warm for less than 2 hours. To stop the keep warm function, simply unplug the unit from the mains.
- Always disconnect the power from the mains before cleaning.
- During cleaning, do not immerse the main body in or rinse it with water.
- Do not use sharp instruments for cleaning to avoid damage the surface of the inner pot.
- Do not operate with broken cord or plug. When it is found malfunctioning, or when damaged, please consult ELEPHANT local service station for any repair or replacement of parts.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by a special cord or assembly available from the manufacture or its service agent.