



## Binyuan Inflatable Bathtub

Safety precautions and instructions for use

For your safety, be sure to use this product according to the instructions

### Safety instructions

Please pay attention to the safety when the heating water is provided for the product, if it is used for the infants, the elderly, the frail, the sick and other special people, there must be a specially-assigned person to monitor in the whole process to avoid the accidents. This product cannot contact with an open fire and the high-temperature objects at 60 degrees Celsius and sharp objects. Read the warnings carefully before use and follow these instructions.

### Do not use this product for the following people

The patients with the heart disease, hypertension, hemophilia, plastic allergy sufferers, patients with the low perception (such as spinal cord injury/easy to burn due to the sensory disturbance), tumors (the tumor is easily diffused by the high temperature), pregnant women, menstrual period, etc., are not suitable for bathing.



Due to the different constitution of each person, some people will have the dizziness and vomiting and other adverse reactions when used for the first few times, this belongs to the normal phenomenon. Because the blood circulation into the body can be promoted by the bathing, the body metabolism is accelerated. In addition, the action of water pressure and buoyancy is considered. For the person with the weak physique and low blood pressure, it is prone to the adverse reactions. If there are the adverse reactions during the bath process, you should stand up slowly and pause the bath in time, and take a short rest to ease the body before continuing the bathing. At this time, the water level should be lowered to the stomach position. Then the water level is gradually raised according to your own adaptation. Also a candy can be contained in the mouth when bathing at the same time, and it also has a certain effect on restraining the dizziness.

### Read the warnings carefully before use and follow these instructions

- ① Never close the detachable cover with the zipper when the bath is filled with water; this will put too much tension on the bath, Only close the zipper before filling the tub.
- ② Never use a telephone or any other electrical appliance in or near the bath when the bath contains water; risk of FATAL electric shock!
- ③ Do not use the electric pump for longer than 5 minutes; let the pump cool down for at least 15 minutes before using it again.
- ④ Do not use the electric pump if the plug or cord is damaged or if the appliance no longer functions properly.
- ⑤ Please keep pets away from the bathtub to prevent damage.
- ⑥ Always use an earthed socket, do not use adapters or extension cables
- ⑦ Do not sit on the bath walls to prevent flooding.
- ⑧ Do not use your bath in combination with alcohol or drugs.
- ⑨ Use your bath near a functioning drain. (A shower or sink for example)
- ⑩ Make sure the drain is the same level or lower than the floor of the Bath
- ⑪ Always make sure there are no kinks in the drain hose and that the end is in the drain before it is filled with water, once full the bath is very difficult to move
- ⑫ If you try to move it, there is a chance that the plastic will crack due to the weight of the water
- ⑬ In the colder areas, please soak in warm water for a while before the first use, and then open and install it after the material becomes soft. The bath tub may be damaged by the direct opening.
- ⑭ Please clean the product with the warm water for the first use, please don't clean the product by use of the corrosive cleaning agent.
- ⑮ When the water-injecting it is recommended to adjust the water temperature to the temperature that is suitable for bathing before the water injecting of the product, The separate injection of the hot and cold water is not recommended, It is recommended that the water level should not exceed the two thirds of the product according to the individual needs.
- ⑯ The bath bucket first use, will contain its own plastic smell, this is normal. Any new product will have a fixed smell. As long as the product is put in the ventilated place after cleaning, the smell will gradually dissipate. If you care about the smell, you can extend the ventilation time. All the materials we choose are environmentally friendly and non-toxic Please rest assured to use them.
- ⑰ The water temperature of the bath is generally between 38-42 degrees, and the optimal time of bath is 15-20 minutes each time.
- ⑱ After the bath, please drain the water in the product completely, and please do not let the product store the water for a long time. The water storage of product for a long time will lead to the product deformation, the service life is shortened.

- ① As required by the design of the production process, the side water outlet will be about 5cm away from the bottom of the barrel, and the remaining water can be discharged by using the bottom water outlet.
- ② It is recommended to use the product in the bathroom, when using it in the other places, the water flooding consequences caused by all kinds of reasons should be considered firstly.
- ③ When the product is injected with the water, be sure not to let the product directly contact with the hot water above 50 degrees Celsius, so as to avoid the phenomenon of bulging in the air circle. Any part of the product will not be damaged as long as the temperature of the water that the human body can tolerate.
- ④ Binyuan or its resellers will in no event be liable for any direct, indirect, punitive, incidental, special, consequential damages, to property or life, arising out of or in connection with the use or misuse of our products.
- ⑤ We want to provide our customers with a great experience with our product. However, safety is always number one.

**FAILURE TO FOLLOW THESE WARNINGS CAN CAUSE(WATER) DAMAGE AND I OR SERIOUS OR FATAIINJURY**



Correct method of use



Incorrect method of use



Bulge phenomenon by scalding

#### Methods of repairing the small broken holes:

First find the broken opening, Clean up the ash layer and water at the hole, cut a patch that is 2 times larger than the hole, apply glue evenly on the hole and the patch, press for at least 30 seconds. After repair, it should be left for at least 4 hours before it can be reused.

#### Methods of repairing the edge gap

Cut out a transparent patch of appropriate size, and then evenly apply glue on the gap and patch, then stick the transparent film on the gap, press it with your hand for about 30 seconds, and leave it for at least 4 hours before reusing it.

#### Repairing the small broken holes



- 1.The repair glue is evenly applied around the broken hole and on the patch.
- 2.Stick the patch to the broken hole and press hard for 30 seconds

#### Repairing the edge gap



1. The repair glue is evenly applied around the gap and on the patch.
- 2.Stick the patch to the gap and press hard for 30 seconds.

#### Installation steps

- ① After opening the package and taking out the tub,unfold it on the ground.
- ② The valve consists of two parts: one transparent plug and one black plug.
- ③ Pull out the transparent plug,hold the wireless pump and inflate the tub at maximum power until there are no folds.
- ④ When the inflation is done,insert the transparent plugs back, and then insert the both valves into the bathtub.
- ⑤ The tub now is ready to use.
- ⑥ Pull out the both black plugs from the valves,and hold the wireless pump and deflate it with the bottom of the pump as a deflator.
- ⑦ There are 3 nozzles of different size which allow you to inflate different items.
- ⑧ In case of breakage ,use the patch and the glue to repair the bathtub. If it is a quality problem of the bathtub,please contact the customer service.



#### Folded Step



- ① All the air in the bathtub is discharged completely.
- ② It is tiled with both sides folded inward.
- ③ It is folded in half into a strip.
- ④ Both ends is folded in half inward.
- ⑤ It is fold in half again to complete.