


Suzhou New District.



Rechargeable Li-ion Battery

36V/41.6Wh EBT360-116B280A

B1

E6

Serial No. BBAJJG4AHB3U2305

Art.No 095.0003.00125-376

**Caution**

1. Use the battery only for the e-bike battery for which it was purchased. Do not use the battery for other e-bikes or devices.
2. Re-charge this battery only with the battery charger which was delivered with the battery.
3. Re-charge this battery only when the environmental temperature is above 0 °C.
4. Do not expose the battery to high temperatures (heaters, direct sunlight or near open fire). Do not immerse the battery in any liquid.
5. When not in use, re-charge the battery every 3 months and store the battery half charged in dry conditions at a temperature between 5 and 25 °C.
6. The battery is a consumable item that is subject to wear. After a period of time the battery capacity is reduced.
7. Follow the charging instructions. This increases the lifecycle of the battery. Read the user manual for detailed instructions.
8. Do not drop the battery. This may damage the battery and/or causes malfunctioning of the battery during use.

**Waarschuwing**

1. Gebruik deze accu alleen voor de e-bike waarvoor deze accu is gekocht. Gebruik de accu nooit voor andere e-bikes of apparaten.
2. Laad deze accu alleen met de oplader die bij de accu is geleverd.
3. Laad deze accu alleen bij een omgevingstemperatuur hoger dan 0 °C.
4. Stel de accu niet bloot aan hoge temperaturen (door verwarming, direct zonlicht of open vuur). Dompel de accu niet onder in een vloeistof.
5. Wanneer niet in gebruik, laad de accu minimaal iedere 3 maanden tot de helft op. Bewaar de accu op een droge plaats bij een temperatuur tussen de 5 en 25 °C.
6. De accu is een verbruiksartikel dat onderhevig is aan slijtage. Na verloop van tijd vermindert de capaciteit van de accu.
7. Volg de laadinstructions. Dit verlengt de levensduur van de accu. Lees de gebruikershandleiding voor uitgebreide instructions.
8. Laat de accu niet vallen. Dit kan de accu beschadigen en/of storingen veroorzaken tijdens het gebruik.

