


Introduction

Thanks for choosing our product.

This product is a smart wireless microphone that provides professional-grade recording output. Plug and play, no app required. Multiple users. It can be used in online live broadcast, video Vlog shooting, program interview, recording, video teaching and other occasions.


The wireless Microphone consists of two parts, one is Microphone Transmitter, the other one is Lightning receiver (see as below picture)



Step 3: The indicator and light of receiver keeps always on, then open the phone camera, live App or other Apps, and then to use the microphone to receive sound.



ID Diagram



- ① Windward net
- ② Microphone holder
- ③ Microphone Type-C charging port
- ④ Microphone tip
- ⑤ Switch key
- ⑥ Microphone reset key
- ⑦ Lightning port to connect phone
- ⑧ Receiver indicator
- ⑨ Reset key of receiver
- ⑩ Type-C port of receiver

* The function of above ⑧ will be specifically explained later.

Special Note:
For the use of Lightning port, there is no battery in Lightning receiver, and no need to recharge during use. If the phone is low power during Use, it can be recharged directly through Type-C port.




Note: Some models do not have this function, and the reset object itself prevails.

How to use

Step 1: Connect the Lightning receiver to phone with Lightning port. The connection is successful if the phone displays a small icon.



Step 2: Press switch key of microphone, the indicator light turns green, and then power is turned on.



About UI

Microphone Transmitter	Light
Function	How to use
Power on	Press switch key once
Power off	Press switch key about 3 seconds
Pausing	Press switch key
Paused	Press reset key once
Power	Press reset key for 3 seconds
Low battery alarm	Power on scale
Charging	Charging with Type-C cable

Type C receiver	Light
Function	How to use
Power on	Plug in the device
Power off	Plug off the device
Pausing	Press light switches
Paused	Press light on

Wireless Microphone

Lightning receiver

User Manual

