



3.How to use?

- If you have make-up on your fac the makeup remover first and the it!
- 1 Moisten your face with clean and evenly apply facial cleans your face.
- ^② Press button for 1.5 second to 1 the machine. If it's first time you can select the operation mo pressing the button continuously
- There are 4 operation modes c choosed. The machine have memory function. Restarting i last gear used.

2



- Light flashes when switching mode
- Charging with breathing light indication
- Light flashes as indication of low battery
- \cdot Light stays on as indication of full charge

on,d rotating magnetic beads function off

Each function mode is switched on and off repeatedly with a long press of one second.

Charging method

The product is magnetic suction charging. One end of the USB charging

other end is connected with the charger or computer USB inter face.

After using the product, it can be charged directly on the base. It is recommended that the charging time should not exceed 24 hours each

.Parameter		6. Attention
Name	Magnetic Bead Massage Facial Cleanser	 Please do not disassemble and refit the product.
Туре	SJ01	
Battery capacity	210mAh	 The product is waterproof and can be washed directly, but it should not be immersed in water for too long.
Surface material	Silica gel	
Base material	ABS	
Charging time	90min	 If abnormal vibration is found during use please check whether the power is low of shut down.
Continuous use time	120min	
Product size	11*53*43mm	
Net weight	126g	 If you do not use it for a long time, pleas close the machine and keep it in a dry plac to avoid direct sunlight.
Input voltage	5V	
Charging current	200ma	
Waterproof grade	IPX7	
Certificate	CE ROHS FDA	

4





8

ice, use hen use	③ Clean by massage in circles from inside to outside,Pay attention to areas where pore is easily blocked, such as T zone, chin, corners of eyes, mouth, etc.	
n water nser on	The recommended cleaning time is 90 seconds. The product has 90 seconds intelligent start-stop function.	
turn on to use, node by sly.	^④ Wash and dry your face with warm water after cleaning.	
can be re gear is the	⑤ Rinse the product directly. Gently wipe the fuselage surface with a clean cloth and place it on the base.	

