

# HUMIPRO+

STANDARD HUMIDIFIER



REFERENCE	POWER	CAPACITY	EVAPORATION MAX.
HUMIPRO 4L	25-35W	4L	350ml/h
VOLTAGE / FREQUENCY 110/220V 50/60Hz			

**4**  
LITERS



## SECURITY

Use this device only for the purpose that it has been designed. No liability will be accepted and guarantee will be invalid in case of improper use or failure to comply with the instructions.

Do not touch the appliance or the power cord with wet or damp hands or feet.

Do not leave the appliance exposed to the elements (rain, sun, frost ...).

Keep the humidifier away from heat sources, radiators, stoves, etc.



While the humidifier is connected, do not neglect its vigilance and keep it out of reach of children. Store it out of reach of children after use.

Do not use the humidifier near furniture or electrical or electronic equipment.

To disconnect the appliance from the mains, gently pull the plug from the socket. Never do it by pulling the cable.

In the event of a fault, anomalies, if the humidifier has fallen, the plug or other parts are damaged, or the cable is damaged, turn off the device and do not attempt to repair it on your own. Contact our technical service.

## BEFORE PROCEEDING TO CLEANING OR MAINTAINING THE HUMIDIFIER, MAKE SURE THAT THE APPLIANCE IS NOT PLUGGED INTO THE POWER SUPPLY.



### DEVICE USE

- 1) Never fill the tank with water that has a temperature higher than 40 ° C.
- 2) Do not add water through nozzle or outlet.
- 3) Use only fresh, clean water. Never add alcohol, perfumed or balsamic oil or any other type of liquid in the tank or in the base.
- 4) Do not use this appliance without water in the tank

### CLEANING THE BASE AND THE NOZZLE

- 1) Clean the plastic surface of the base and the nozzle with a damp cloth and dry it with a dry one.
- 2) Do not use alcohol or abrasive products.

### CLEANING THE DEPOSIT

- 1) the cleaning of the deposit should be done once a week.
- 2) unscrew the tank cap and drain the water as indicated above.
- 3) Fill the tank with clean, fresh water.
- 4) Put the cap on and shake the tank for a few seconds.
- 5) Remove the plug and pour the water.
- 6) Completely clean the cap and the part of the tank thread with a damp cloth and dry it with a dry one.
- 7) Do not use alcohol or abrasive products.
- 8) Clean the surface of the tank and the inside of the tank outlet tube with a damp cloth and dry it with a dry one.

### CLEANING THE TRANSDUCER MEMBRANE

- 1) The cleaning of the membrane should be done once a week, but if you see dirt in it or the cold vapor flow decreases, the cleaning of this piece should be done immediately.
- 2) Empty the water contained within the base of the humidifier
- 3) Completely dry the inside of the base of the appliance with a dry cloth, place 2 or 3 drops of the cleaning liquid on the transducer membrane and allow approximately one minute to elapse.
- 4) Clean the membrane with a small brush and once the membrane has been cleaned, dry it completely with a dry cloth.