



MASSAGERR




MASSAGE DUO BALL MANUAL

www.massagerr.nl

INSTRUCTIONS

www.massagerr.nl



FUNCTION BUTTON

PRESS POWER BUTTON:

- ONE** Turn on power and charging indicator
- TWO** First speed's vibration (1 speed indicating)
- THREE** Second speed's vibration (2 speeds indicating)
- FOUR** Third speed's vibration (3 speeds indicating)
- FIVE** Fourth speed's vibration (3 speeds intermittent)

CLEANING & MAINTENANCE

www.massagerr.nl

- The unit will power off automatically after 10minutes of use (This is to prevent overheating).
- The unit can not be used continuously in the third mode for over 60minutes (This is prevent overheating).
- Please do not drop, throw or slam the product in any case.
- The unit is IP65 Standard Waterproof, please use properly. Do not use if cracked, damaged or other issue.
- Keep unit clean and dry, use storage bag when not using.

SPECIFICATIONS

Net Weight: **540g**

Charging Time: **2-4hours**

Motor RPM: **2000 > First Speed**
4000 > Second Speed
6000 > Third Speed

Motor Temperature: **65°C**

Material: **ABS+silicone**

Battery: **DC 3.7V 2500mAh**

Working: **Maximum speed**

Time: **50 mins (5 cycles)**
10 mins per cycle

CHARGING

www.massagerr.nl

The product can be charged with any charging adapter / power with voltage from **3.7V to 5.0V**. You may use a laptop or desktop comter, mobile power bank, or cellphone charger.

WHILE THE UNIT IS CHARGING:

- Charging time is 2-4 hours. Actual charging time depends on its remaining power
- The power and standby indicators will be flashing red and blue while charging
- The unit can not be turned on while charging
- When fully charged the indicator light will be red



Follow us on Instagram



Made in China

