



Super Tanning

RT8801

Please read the Instruction Manual thoroughly before using this appliance.



Super Tanning

RT8801

Instruction MANUAL

Thank you very much for purchasing Super Tanning. This appliance is an ideal facial tanner with which you can suntan comfortably at home all year round.

Important Advice

- ▲ Never use the appliance in wet surroundings.
- ▲ Do not use the super tanning if your skin has been overexposed to the sunlight on that day.
- ▲ Do not tan your face more than once a day.
- ▲ Always use the protective goggles supplied with the super tanning while tanning to protect your eyes against overexposure to ultraviolet radiation.
- ▲ Never use the super tanning if the timer, power cord, or other electrical mechanisms are damaged or do not function properly.
- ▲ If your skin feels taut after the tanning session, you may use some moisturizing cream
- ▲ Never let the super tanning be used by children or person who suffer from skin cancer.
- ▲ Always remove the plug from the socket after use.

How to use the appliance

1. Place the super tanning on a level surface.
 - ▲ The appliance can be adjusted to 2 positions.
2. Plug in the appliance.
3. Consult the table below to determine the appropriate duration of the tanning session.
4. Put on the protective goggles.
5. Turn the dial of the timer to the right to the desired time. The timer will automatically shut off the appliance after the set time has elapsed.
6. Position yourself in front of the appliance.
 - ▲ Keep a distance of about 10cm between your face and the appliance.
 - ▲ Turn your face from time to time to get an even tan.
7. Always unplug the appliance after use.
 - ▲ You may keep track of the overall number of sessions you have had with the memory knobs on the face of the appliance.

Maintenance & Cleaning

First of all, remove the plug from the socket and let the appliance cool down. Then you may clean the outside of the appliance with a soft, damp cloth. Make sure that no water gets into the appliance. The reflector should only be dusted with a very soft brush. Do not use any liquid such as petrol or acetone.



Replacement

The tube lamps have a normal operating life of about 300 hours, which is approximate equivalent of two (2) years of moderate use. The tube lamps or any other electrical parts should only be replaced by qualified electrician. Never disassemble the appliance unless you are a qualified electrician.

Tanning sessions

It is very important that the user read these instructions thoroughly before use of this appliance.

- ▲ Person with very sensitive skin who burns easily and severely but does not tan when exposed to the sun is not advised to use this appliance.
- ▲ Do not exceed the recommended tanning times and the maximum number of tanning hours.
- ▲ For this super tanning the maximum is 35 hours per year
- ▲ Should your skin become taut and tender after the tanning session, it is advised that you reduce the session by e.g. 5 minutes.
- ▲ The max exposure time for one session is 30 minutes. Avoid overexposure.
- ▲ After finishing a tanning program, a maintenance tanning session of 30 minutes a week is sufficient to keep your tan.
- ▲ You may start a new tanning program one month after a tanning program.

	Person with very sensitive skin	Person with normal sensitive skin	Person with less sensitive skin
1st session	10	10	10
Break of 48 hours	--	--	--
2nd session	15	20	30
3rd session	15	20	30
4th session	15	20	30
5th session	15	20	30
6th session	15	20	30
7th session	15	20	30
8th session	15	20	30
9th session	15	20	30
10th session	15	20	30
	Duration of tanning session in minutes		

Caution

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.



Super Tanning

RT8801

UV tube lamps 15W (4x)

Protective eye goggles 2pairs included.

230V~50Hz



INSTRUCTIONS FOR ENVIRONMENTAL PROTECTION

Do not dispose of this product in the usual household garbage at the end of its life cycle. Hand it over at a Collection Point for recycling of electrical and electronic appliances. The materials are recyclable as shown by the symbol. By recycling or other forms of re-utilization of old appliances, you are making an important contribution to protect our environment.



扫描全能王 创建