




Professional Hair Clipper

K115

Operation Manual

Components



Parameters

Professional Hair Clipper	Motor	Operating voltage: 5V/1V High performance motor
	Battery	2000mAh Li-ion battery Rechargeable about 10 hours Working time with full charge about 10 hours
Applicable Adapter Type	Input	100-240V~50/60Hz
	Output	5V=1000mA Maximum power 5W. Otherwise the device will burn out, resulting in a permanent and irreparable 0%.

1

English

Precautions For Use



ADD NOT disassemble the product by yourself.
ADD NOT wash the hair clippers, keep them away from wet areas.



A The product should only be cleaned with a lightly dampened cloth or a mild soap solution.
ADD NOT charge the product within temperature ranges of above 40°C or below 0°C. Otherwise the battery's capacity will be reduced and its lifespan will be shorter.
B Output **CANNOT** exceed 5.5V, otherwise the device will burn out, resulting in a permanent and irreparable 0%.


1. The product will become warm during usage and charging, this is normal.

2. Please remove the battery safely, and follow all proper protocols in your area or battery disposal, when the battery is service life ends.

2

English

Instruction



LED Display



Power Indicator Percentage



• If there is a lack of oil, the red light on the left side of the clipper turns on and there is an audible reminder at the same time.
• If the battery is below 5%, the red light on the right will flash.

3

English

Fixed-Length Function

A: Use of guide Comb: Drop and into the hair Options (3.5, 4, 6, 8, 10, 12mm) as length adjustment options, they help to control the length of the hair that is cut.

- To determine the length of the haircut.
- To select the appropriate guide Comb for styling and trimming.



• To adjust the clippers

These clippers are equipped with an adjustable taper lever that changes the closeness of the hair trimming. When the lever is in the uppermost position, the blades will produce the closest clipping. Pushing the lever downward gradually will increase the cutting length, as a result less hair will be cut.



Install the guide Comb:

- Align the guide Comb with the blade edge
- Slightly pressed down on it until there is a Snap in order to insert it.

Disassemble the guide Comb:


Put the guide comb firmly at its base (not along the teeth) until it disconnects from the clippers.



4

English

Use the Rechargeable Mode



How To Recharge


- Insert the charger into the rear part of clippers, connect to a power supply to begin charging.
- When the charging indicator light comes on, charging has commenced, when the red light changes to blue, it indicates the product has been fully charged. Cord and cordless options are available.

5

English

Assembly & Disassembly Of The Clippers

The blades must be re-align if they have been removed for cleaning or replacement. As shown in the image to the right the bottom blade holes are wider than the shanks of the blades screws. After the screws of the bottom blade is loosened, adjust the distance of lower blade, and align it with the upper blade, then tighten it.



This must be done so that the clippers will not cut too closely or allow any moving parts to come in contact with the skin.

- The left-most tooth of the upper blade must be covering or in the left position of the first small tooth of the bottom blade.
- The right-most tooth of the top blade must be touching the large tooth on the bottom blade.

Maintenance of Clippers



- The clippers have been carefully tested to ensure they are used and aligned properly before leaving the factory.
- To keep the clippers performing at the highest capacity they must be oiled after several uses. To oil it properly, the oil should be held so the blades are in a downward position. With the clipper blade running, dispense 2-3 drops of oil across the top blade.

6

English

For more information, contact us at:
info@goodsexperiences.com
www.goodsexperiences.com

Manufacturer:

Kaogee / Good Experience

throughout EU

ARTEC Breda

The Netherlands

CE RoHS

Made in China