


面板介绍



本产品是气氛灯具，不是照明灯具，一般夜晚或者光线暗的场所使用最佳，灯光效果最佳距离10米内

舞台娱乐 从一台灯开始

遥控器面板介绍



	开/关		LED自走模式，按此键后可以单选择LED的颜色，如果不按此键是不可以选LED颜色
	电机暂停		红色LED常亮
	频闪模式		绿色LED常亮
	自走模式1，红绿激光循环亮，LED蓝光常亮		蓝色LED常亮
	自走模式2，绿激光常亮亮，LED七彩渐变		红蓝色LED常亮
	自走模式3，红激光常亮亮，LED七彩渐变		红绿色LED常亮
	声控模式1，此声控是劲爆模式，有声音亮，没有声音关灯。爆闪十足		绿蓝色LED常亮
	声控模式2，此声控是动感声控模式，有声音红绿激光+LED灯循环亮，电机速度快转		红绿蓝色LED常亮
	声控模式，此声控是抒情声控模式，有声音红绿激光+LED灯循环亮电机速度慢转		定时1小时. 在选择自己喜欢的模式下按此键可以定时1小时
	此模式是红绿激光常亮，可以选择LED. R. G. B. RB. RG. GB. RGB来搭配。如果按了LED搭配不需要LED时在按回此键就红绿光常亮		定时3小时. 在选择自己喜欢的模式下按此键可以定时3小时
	此模式是红激光常亮，可以选择LED. R. G. B. RB. RG. GB. RGB来搭配。如果按了LED搭配不需要LED时在按回此键就红光常亮		定时6小时. 在选择自己喜欢的模式下按此键可以定时6小时
	此模式是绿激光常亮，可以选择LED. R. G. B. RB. RG. GB. RGB来搭配。如果按了LED搭配不需要LED时在按回此键就绿光常亮		定时8小时. 在选择自己喜欢的模式下按此键可以定时8小时

产品参数


激光光源：532nm绿光激光器、650nm红光激光器、
LED光源：三合一RGB灯珠
供电需求：AC100V~240V, 50Hz~60Hz
适配电源：DC5V/1A~2A
使用环境：10~40°C 室内
预热时间：2~8分钟
控制模式：手动、遥控
工作方式：声控、自走、频闪
冷却系统：风机强制冷却系统
扫描系统：精密电机

安全事项

- 该产品属IIIB类激光产品，应避免眼睛贴近出光孔位置受到激光照射，否则可能引起眼睛不适。
- 勿让儿童独自操作本产品，其他人操作前请进行安全提示。
- 本产品适于室内使用，其防护等级为IP20。适于干燥环境，请避免在潮湿、过热、多灰尘的环境中使用。产品周围要散热良好，远离易燃物体或者液体。
- 请使用本司所提供的电源适配器给产品供电。如需更换适配器请参照原适配器的参数选配。如需延长电源线，请使用足够直径的合格线材，并控制延长长度，以免线损过大导致适配器负载过高



Front cover and rear cover



This laser light can create best atmosphere for different environment, it is not for illumination. At night or some dark places, it will show perfect atmosphere to cover around 50 square meters room.



Remote Control Function



	Power switch		LED color changes automatically, press this button can also choose different led color.
	Motor stop		Red LED color only
	Strobe mode		Green LED color only
	Automatic mode 1, red and green laser light changes while Led light is always blue.		Blue LED color only
	Automatic mode 2, LED changes different color while Laser light is always red and green.		Red and Blue color LED only
	Automatic mode 3, LED changes color with JUMP while Laser light is always red and green.		Red and Green color LED only
	Sound active mode 1. The sound active sensor works in high level of sensitivity, light works immediately with some SOUNDS, and turn off immediately without SOUNDS.		Green and Blue color LED only
	Sound active mode 2, the motor works fast, if add some SOUNDS in the environment, Laser color and LED color changes cycling.		Red Green Blue color LED only
	Sound active mode 3, the motor works slow, if add some SOUNDS in the environment, Laser color and LED color changes cycling.		Definite Time 1 hour, choose your love mode and press this button, light will work 1 hour only.
	Red and green laser color is always working, it can be matched with different LED colors: R G B RB RG GB. Press this button can cancel the chose LED color.		Definite Time 3 hours, choose your love mode and press this button, light will work 3 hours only.
	Red laser color is always working, it can be matched with different LED colors: R G B RB RG GB. Press this button can cancel the chose LED color.		Definite Time 6 hours, choose your love mode and press this button, light will work 6 hours only.
	Green laser color is always working, it can be matched with different LED colors: R G B RB RG GB. Press this button can cancel the chose LED color.		Definite Time 8 hours, choose your love mode and press this button, light will work 8 hours only.

Product Parameter

Laser diodes: Green laser diode 532nm, Red laser diode 650nm
LED diode: RGB 3IN1 Led
Power supply: AC100-240V, 50/60Hz
Power adaptor: DC5V, 1A-2A
Working environment: 10-40°C indoor
Preheat time: 2-8 minutes
Control mode: Manual, Remote control
Play mode: Automatic, Sound active, Strobe
Cooling system: Fan
Scan system: Precise motor

Safety Notes

- This laser light is class 3B product, it is prohibits to expose the naked eyes directly to the Laser, otherwise it may injure the eyes.
- It is prohibits to let the kids play this product. Before operate this laser light, every people must read the safety notes.
- This product is used indoor only, IP20. Don't use it in Moist, overheated, dusty environment. It should be operating in a nice aerating environment, keep far away from flammability materials or liquid.
- Please use the adaptor provided in the packing. If need to replace the adaptor, please refer to the product parameter. If need to extend the power cables, the extended cables' diameter must meet qualified requirement; please don't extend the cables too long, otherwise the adaptor will be broken easily.

