## **Usage Method**



 Take appropriate amount of dehairing Wax Beans and put them into the heater tank for heating.



Heat to melt and take it out. When the temperature is suitable, take out the wax adjusting rod for use.



 Keep the skin clean and dry, and take appropriate amount of depilatory wax with depilatory stick. Apply a thin layer of hair removal wax evenly along the direction of the hair.



4. Wait for the depilatory wax to solidify and stick, and tear it away quickly against the direction of hair growth. The hair will be pulled out with the depilating wax.



 This product is made of environment-friendly and high-quality materials. The unused ones need not be poured out. It can be cooled and reheated again next time.



Depilation is completed, showing a smooth skin.