



e 609 silver

Instruction manual



Delivery includes

- e 609 silver
- pouch
- quick guide
- safety guide

Product overview



- 1. Sound inlet basket
- 2. XLR-3 connector
- 3. Front


SENNHEISER e 609 | 2/7



Installation


Attaching the microphone

- $\, \triangleright \,$ Screw the microphone clamp to a stand.
- ▶ Place the microphone with its back end into the microphone clamp.
- ▷ Orient the microphone together with the microphone clamp.



Connecting the microphone

▶ Connect the XLR-3 socket of the microphone cable (optional accessories) to the XLR-3 socket of the microphone.




SENNHEISER e 609 | 3/7



Operation

Positioning the microphone

- $\, \triangleright \,$ Position the microphone between the dust cap and surround.
- ▶ The front must face the loudspeaker.






▷ It is vital to observe the following notes:

| Position | Resulting sound | Commentary |
|----------|---|--|
| A | many trebles aggressive sound | microphone directed towards the dome of the loudspeaker |
| В | less trebles, more lower mids, smoother sound balanced, natural sound | good starting position: microphone directed towards the middle between dome and edge of the loudspeaker If necessary, turn the microphone by approx. 30° towards the edge. |
| С | less trebles, more lower mids, smoother sound | microphone directed towards the edge of the loudspeaker |






В



С




SENNHEISER e 609 | 4/7



Positioning the monitor loudspeakers

▶ To prevent feedback and crosstalk, postion your monitor loudspeakers in the angle area of the highest cancellation of the microphone (approx. 135°).




Cleaning and maintaining the e 609 silver

CAUTION

LIQUIDS CAN DAMAGE THE ELECTRONICS OF THE PRODUCT!

Liquids entering the housing of the product can cause a short-circuit and damage the electronics.

- Do not use any solvents or cleansing agents.
- Disconnect the products from the power supply system and remove rechargeable batteries and batteries before you begin cleaning.
- $\, \triangleright \,$ Clean all products only with a soft, dry cloth.




SENNHEISER e 609 | 5/7




Specifications

| Transducer principle | dynamic |
|-----------------------------------|------------------|
| Frequency response | 40 - 15,000 Hz |
| Pick-up pattern | super-cardioid |
| Sensitivity (free field, no load) | 1.5 mV/Pa |
| Nominal impedance (at 1 kHz) | 350 Ω |
| Min. terminating impedance | 1 kΩ |
| Connector | XLR-3 |
| Dimensions | 55 x 34 x 134 mm |
| Weight | 140 g |

Polar pattern




Frequency response



SENNHEISER e 609 | 6/7




Connector assignment



Overview of applications

- Primary application
- Secondary application



SENNHEISER e 609 | 7/7