

Cautions

- DO NOT remove the lid or add in something rigid in your blender when it is blending.
- DO NOT submerge the base into water to prevent base elements from damaging and make sure it is off before cleaning.
- DO NOT disinfect your blender in microwave or hot water above 80°C.
- DO NOT put your blender in freezer.
- DO NOT clean your blender with any kind of metallic spiral ball to prevent parts from scratching or damaging.
- DO NOT clean your blender with a dishwasher machine.
- DO NOT charge your blender when it is wet.
- DO NOT repair or disassemble it by yourself otherwise your warranty will be void. If malfunction occurred, kindly contact us.

Your First Blend

Make sure your blender is fully charged by checking whether all indicator lights are blue before your first blend. Tighten the body and base until the magnet is aligned with the power button. Remember to clean it immediately after use.



Step 1

Cut fruits into small pieces before adding into the blender to fill up about 60% of the jar capacity.



Step 2

Add some drinkable liquid until it reaches 80% of jar capacity.



Step 3

Tighten the lid and tilt down the blender to make sure fruit pieces are not stuck under the blades.



Step 4

Blend Mode: Click once power button to start blending. Slightly tilt it back and forth while blending if desired.
Pulse Mode: Double-click power button to enter into pulse mode. Press and hold the power button repeatedly to pulse. Pulse mode will automatically end after 5S of inactivity.