

## 1.4-LITER COOKING SYSTEM

## INSTRUCTIONS FOR USE

- Remove lid from pot and extract burner kit
- Ensure control valve is closed by checking that it is fully turned to the right (clockwise)
- Check that the 'O' ring is in place on the burner valve and that the unit is not damaged, worn or clogged with debris.
- Connect the burner to the canister by holding the canister and rotating the burner clockwise. Take care that the screw threads are
  correctly lined up and that the burner is securely tightened. Never overtighten, as damage can result to the burner and/or fuel canister
  thus creating a safety hazard.
- To light the stove, ensure that you are in a well ventilated area, open the control valve (by turning counter-clockwise) and press the self
  igniter button. Ensure that the burner is alight before fitting the pot to the burner.
- Ensure that the pot sits snugly inside the locking ring and that the lugs are engaged.
- Ensure that the pot is not filled beyond the midpoint to prevent spillage whilst boiling.
- Always use the insulated handles and/or neoprene sleeve during use and to support the pot when removing the lid or the pot from the burner. Touching exposed metal parts when cooking/heating will result in injury.
- · To extinguish the flame, turn the control knob fully counter clockwise.
- Take care as the pot and burner will be hot for some time after use. Please let the burner cool before packing the stove away.
- Remove canister from burner prior to storage and store in a cool, dry place.

## WARNINGS

- ALWAYS USE OUTDOORS IN A WELL VENTILATED AREA NOT FOR INDOOR USE. Do not use in a confined space such as a tent, camper, car, RV, or home, as all stoves generate Carbon Monoxide which has no odor and can pose risk of carbon monoxide poisoning and fire.
- If you smell gas or hear gas escaping prior to opening the control valve, please check that the valve is fully closed (clockwise) and that
  the canister is firmly attached to the burner. If this problem persists do not ignite the stove.
- · When changing canisters, please ensure that you are in well ventilated area away from any naked flames or sources of ignition.
- · Do not use any pot other than the one supplied, as an alternative design may cause the stove to overheat and potentially explode.
- Do not leave unattended while lit.

