

ULTRA SLIM USB WIRED KEYBOARD
FOR MAC

User's Guide



www.macally.com

Shortcut Keys

Shortcut mode - Shortcut mode is the default mode if Fn and esc keys are pressed together. Fn Lock LED is turned on. Keyboard is in Fn Lock mode. You can press Fn and esc keys together again to toggle back to Shortcut mode.

- ☀ Brightness change to Mac built-in display
- ⌘ Out (Cmd-X)
- ⌘ Copy (Cmd-C)
- ⌘ Paste (Cmd-V)
- ⌘ Previous Track (Cmd-Left Arrow)
- ⌘ Play/Pause (Spacebar)
- ⌘ Next Track (Cmd-Right Arrow)
- ⌘ Force Out Application (Cmd-Option-Esc)
- ⌘ Spotlight Search (Cmd-Spacebar)
- ⌘ In Mac, press 1 second to turn off screen, or press and hold 3-5 seconds to bring up Power/Status Down-menu
- ⌘ Mute
- ⌘ Volume Down
- ⌘ Volume Up
- ⌘ Eject
- ⌘ Print (Cmd-P)
- ⌘ Full screen capture (Cmd-Shift-G)
- ⌘ Area screen capture (Cmd-Shift-H)
- ⌘ File save (Cmd-S)
- ⌘ Zoom Out (Cmd-Minus)
- ⌘ Zoom In (Cmd-Equal)

Introduction

Thank you for purchasing the Macally ACEKEY. It is designed with lots of shortcut features and flexibility and will greatly improve your productivity.

Before you begin using this product, be sure to read this user's guide in its entirety.

Package Contents

- USB Keyboard
- User's guide

Macally Product Information

Technical Support

Please E-mail us at techsupport@macally.com, in U.S.A. please call 1-800-320-8888
Mon-Fri 8:30 AM - 8:30 PM, Pacific Standard Time

Macally Product Information

Warranty

Macally purchases warrants that this product will be free from defects in the materials and manufacturing workmanship for two years from the date of purchase. If the product is found to be defective then, at your sole remedy and at the manufacturer's only obligation, Macally will repair or replace the product. This warranty shall not apply to products that have been subjected to abuse, misuse, abnormal structural or environmental conditions, or any condition other than that which can be considered as normal use.

Limitation of Liability


The liability of Macally Peripherals arising from this warranty and sale shall be limited to a refund of the purchase price. It is to be noted that Macally Peripherals is liable for costs of procurement of substitute products or services, if for any reason, or for any consequential, incidental, direct or indirect damages, however caused and on any theory of liability, arising from this warranty and sale. These limitations shall apply not with standing any failure of essential purpose of any limited remedy.

Copyright © 2018 by Macally Peripherals

System Requirement

- Mac OS X 10.3 to 10.13 and above
- Any desktop and notebook computer with a USB port available

Hardware Basics



Fn LOCK MODE

Function keys F1 to F16 and blue color keys
Press "Fn" key with "esc" key simultaneously to switch to Fn Lock mode as default.



More about mode

1. Shortcut mode is restored to default mode after ACEKEY loses power, e.g. when unplugged from a computer or a computer is shut down or restarted.
2. In other Shortcut mode or Fn Lock mode, one can also press "Fn" key with one of top row key alternatively to perform the secondary function without switching mode.

Keyboard Shortcuts for MacOS X

Previous section has described default shortcuts and Function Keys. They are supported in MacOS X from 10.3 to 10.13 and above, no driver installation is needed. Please note, these shortcuts are not universal, certain shortcuts do not work as defined in some applications. On the other hand, some shortcuts may act completely different way in different applications. You should try them out first.

Keyboard Setup Assistant

In Mac, the first time you plug in this new keyboard to use, desktop will pop out a "Keyboard Setup Assistant" window. Please follow the on-screen instruction to identify the keyboard before you can use the keyboard correctly.

After initial setup, if you experience any issue with keyboard or couldn't type correctly, please unplug and replug the keyboard, open keyboard icon in System Preferences, click on "Change Keyboard Type" icon to run Keyboard Setup Assistant to re-identify the keyboard.

