


**OSPREY**

8+

# **DIRT SCOOTER**



**OSPREY**

TY5299 / TY5300 / SK2002 / SK2004 / SK2005

For ages: 8+

Max user weight: 100kg

Please retain this information for future reference.


Wilton Bradley Ltd, Heathfield, TQ12 6TL, UK

Design rights © 2013 WBL. Osprey® is a registered trade mark of WBL.


**OWNERS MANUAL**

## ASSEMBLY


1.



2.



3.



## PARENTS


Adults must assist children in the initial adjustment procedures to unfold scooter, adjust handlebar and steering to height, and finally to fold scooter. You are responsible for your child's safety. Read and explain the information in this manual to your child.

## MAINTENANCE

- Replace worn or broken parts immediately
- Use a wrench to check your front and rear bolts to ensure they are tight.

### Inflating tyres

- The tyres are inflated when shipped but may lose some pressure between the point of manufacturing and your purchase.
- Always inflate tire to the correct PSI before use.



Using a bicycle-style tire pump equipped for a Schrader-type valve, inflate the front tire to the correct PSI indicated on the sidewall of the tire.

### Cleaning your scooter

- Wipe with a damp cloth to remove dirt and dust.
- To clean grip tape, use a wet coarse brush to scrub any dirt stuck to the surface and let it dry.

## SAFETY

- Obey all local traffic and scooter riding laws and regulations
- Always wear safety equipment such as helmet, wrist guards, knee pads, elbow pads. Always keep the chinstrap of your helmet securely buckled. Always wear shoes. We strongly recommend wearing gloves, long sleeves, long pants and hip pads.
- Ride on smooth, paved surfaces away from motor vehicles.
- Avoid sharp bumps, drainage grates, and sudden surface changes. Scooter may suddenly stop.
- Avoid streets and surfaces with water, sand, gravel, dirt, leaves and other debris. Wet weather impairs traction, braking and visibility.
- Never ride under the influence of alcohol or drugs.
- Do not ride at night.
- Brake will get hot from continuous use, do not touch after braking.
- Avoid excessive speed associated with downhill rides.
- Before use, check that the steering system is correctly adjusted and that all connection components are firmly secured and not broken.
- Watch out for pedestrians.
- Before riding assess all obstacles and potential dangers both natural and manmade.
- Check and secure all fasteners before every ride.

### How to use

- To use, place one foot on the deck of the scooter and push off the ground using your dominant foot. To brake, press the rear mechanical brake until it is touching the wheel to come to a stop.