

Care and use guide

	Contents	page
	Features	2
	Quick guide	2
	To operate	3
	Cleaning	4
1250	Battery replacement	4
66	Calibration	5
(4)	Error messages	5
	Troubleshooting guide	6
	Technical specifications	6
8	Information about the scales available on the Bluelab ppm Pen	7
	Product guarantee	8
E C	Blulelab Probe Care Kits	9
(a)	Contact details	9
and a	West	







Features	
Backlit LCD display	Calibration optional
Hold reading function	Fully waterproof
Fully guaranteed for 1 year	Auto off function
Low battery warning	Automatic Temperature Compensation (ATC)
Successful calibration indicator	Selectable units for conductivity and temperature



accurate as the probe is clean



ensure an accurate reading (see cleaning instructions in section 2.0).



1.0 To operate

Turn pen on

Press power button. The last measurement is recalled for 3 seconds.

To turn pen off

Press and hold the power button until OFF is displayed.

NOTE: The pen will automatically turn off after 4 minutes to conserve battery power.



Power button

Measure ppm

Place probe in solution and wait for reading to stabilize.



If you want to "hold" the reading on the screen, short press the power button. To exit the hold function press the power button again.



1 second alternating displays









To change units

Hold down the units button for 3 seconds until the conductivity and temperature units start flashing. Short press units button again to cycle between unit combinations. To exit this mode don't press anything for 3 seconds.

NOTE: You can change units while in hold mode by holding down the units button.

Sinse conductivity probe

To reduce the build up of nutrient salts, rinse under running water after each use.

The probe needs to be cleaned once every two weeks to ensure accurate readings. To clean the probe follow the cleaning instructions in section 2.0.



2.0 Cleaning

Cleaning the ppm pen probe periodically ensures accurate readings.

The probe is cleaned using the Bluelab Conductivity Probe Cleaner, or "Jif" a trade name for a liquid scourer cream used in home bathrooms and kitchens. Similar products are called "Liquid Vim", "Soft Scrub", "Cif cream", or "Viss".

Never use scented varieties as they contain oils that contaminate the probe.

Follow the steps below to clean the probe.

Remove shroud. Hold the body and pull the shroud off. Holding your hand around the shroud for a few seconds will help with removal.

Clean probe face.

Place one or two drops of probe cleaner onto the probe face and rub with your finger or Bluelab Chamois firmly and vigorously, to clean the probe face.

If a heavy build up occurs around the temperature sensor clean with a soft toothbrush to remove contamination.

Rinse probe.

Rinse off all traces of cleaner under running water using the same finger or other side of Bluelab Chamois. Check that the water forms a film on the probe face with no "beads" of water. If beading is present repeat the cleaning process.

Replace shroud and test in a known solution to ensure the unit has been adequately cleaned.







3.0 Battery replacement

The ppm pen is powered with 1 x AAA alkaline battery. Do not use rechargeable batteries. A low battery warning is indicated by a battery symbol appearing on the screen. Only remove the battery cap when the batteries require changing. Battery life is expected to be 350 hours.

- To remove old battery Undo battery cap fasteners. Remove battery cap and tip out the old battery.
- Check for corrosion
 Flat batteries may leak and cause corrosion. Check battery contacts and the battery for any sign of corrosion. Battery contacts should be cleaned first if corrosion is found before proceeding to step 3.
- Fit new battery Insert the new batteries positive (+) end down into the body.
- Ensure waterproof battery cap seal is clean Seal will fail if any dirt is present.
- Seplace battery cap Tighten fasteners on battery cap until there is no space left between the cap and body. This ensures the unit remains 100% waterproof.



Waterproof seal





4.0 Calibration

Calibration of conductivity is not required for this unit as it is factory calibrated. However; if you wish to calibrate the unit follow the instructions below.

40 YOU MUST CLEAN THE PROBE BEFORE CALIBRATING.

See section 2.0.

Rinse probe in fresh water and place it in a known standard solution. See chart below for the correct solution.

Wait for reading to stabilize.

Hold down the cal button for 3 seconds until CAL appears.


Release button and CAL P should be displayed. If Err is displayed check the probe is clean and that the calibration solution is fresh and uncontaminated.


A check mark will appear on the screen to indicate that the calibration was successful. The check mark will disappear after 30 days. To reset back to factory default remove/replace battery.

	EC	ppm 500 (TDS)	ppm 700 (EC x 700)
Solution value	2.77	1385	1940
Displayed value	2.8	1390	1940

NOTE: If you need to test or calibrate in a 1500 ppm solution, you MUST set the pen to EC, then multiply your result by 540. If calibrating, multiply 2.8 by 540 $(2.8 \times 540 = 1512).$

This unit DOES NOT measure in the 540 ppm scale.







5.0 **Error messages**

The following error messages appear for the following reasons.



Temperature under range



Temperature over range



Temperature error



Hardware error



ppm over range



6.0 Troubleshooting guide Trouble Correction Low readings usually mean the probe is contaminated. Clean the probe and retest in a known solution. Ensure unscented cleaner is ppm pen gives low used eg. Bluelab Conductivity Probe Cleaner, Jif, Liquid Vim, Soft readings Scrub, Cif cream or Viss. Calibrate pen in a known standard solution. Check the table in section 4.0 for what solution to use for your ppm pen gives high readings selected conductivity unit. Replace unit. Screen does not turn on

7.0 Technical specifications			
Range	0.0 - 10.0 EC, 0 - 7000 ppm (700 ppm), 0 - 5000 ppm (500 ppm/TDS) 0 - 50 °C / 32 - 122 °F		
Resolution	0.1 EC, 10 ppm (700), 10 ppm (500) 1 °C / 1 °F		
Accuracy	± 0.1EC @ 25°C (@2.77EC) ± 50 ppm (ppm 500) @ 25 °C (@ 1385 ppm) ± 70 ppm (ppm 700) @ 25 °C (@ 1940 ppm) ± 1 °C/±1 °F/±2 °F		
Temperature compensation	Automatic		
Operating temperature	0 - 50 °C, 32 - 122 °F		
Calibration	Factory calibrated / manual calibration optional		
Units	EC, 700 ppm, 500 ppm, °C, °F		
Power source	1 x AAA alkaline battery		

Limitation of Liability

Under no circumstances shall Bluelab Corporation Limited be liable for any claims, losses, costs and damages of any nature whatsoever (including any consequential loss) that result from the use of, or the inability to use, these instructions.



8.0 Information about the scales available on the Bluelab ppm Pen

EC

Is a measure of electrically charged nutrient ions in a solution and is the only absolute measure of conductivity.

Pure water will not conduct electricity. Water usually conducts electricity because it is full of impurities, in our case, electrically charged nutrient ions. The two black dots on the end of a conductivity probe are called electrodes. When these are placed in a solution, an electrical current passes from one electrode, through the water to the other electrode and counts the number of electrically charged ions present. This represents the units measured - EC.

ppm measures parts per million

There are many different scales used for different industries around the world and for many different reasons! Did you even know there are more than two scales? The most widely used scales in Hydroponics are the 500 scale, 650 scale and the 700 scale.

What's the difference?

The ppm 500 scale is based on measuring the KCl or potassium chloride content of a solution. The ppm 700 is based on measuring the NaCl or sodium chloride content of a solution. Individual nutrient ions have different electrical effects! The true ppm of a solution can only be determined by a chemical analysis. ppm cannot be accurately measured by an EC meter. They are present on Bluelab products as a conversion guide only. The conversion is as follows;

```
2.4 \text{ EC x } 500 = 1200 \text{ ppm } (500 \text{ scale}) \text{ or } 1200 \text{ ppm } / 500 = 2.4 \text{ EC} 2.4 \text{ EC x } 700 = 1680 \text{ ppm } (700 \text{ scale}) \text{ or } 1680 \text{ ppm } / 700 = 2.4 \text{ EC}
```

If you are wanting to measure your solution in ppm, you will need to know the following:

- What ppm scale is your meter using?
- Which calibration standard should you use for your meter?
- What ppm scale is my nutrient referring to?



Bluelab ppm Pen product guarantee

Bluelab Corporation Limited guarantees this product for a period of **1** year (**12** months) from the date of sale to the original purchaser. The product will be repaired or replaced, should it be found faulty due to component failure, or faulty workmanship. The faulty product should be returned to the point of purchase.



The guarantee is null and void should any internal parts or fixed external parts be tampered with or altered in any way, or should the unit have been incorrectly operated, or in any way be maltreated. This guarantee does not cover reported faults which are shown to be caused by any or all of the following: contaminated measuring tip (see instruction manual for cleaning instructions), broken glassware or drying of the pH probe glassware, flat or damaged batteries or batteries that have been incorrectly inserted, or damaged battery contacts or connections caused by incorrect battery replacement or ingress of moisture from incorrect positioning of the battery cap and waterproof seal.

NO RESPONSIBILITY will be accepted by Bluelab or any of its agents or resellers should any damage or unfavourable conditions result from the use of this product, should it be faulty or incorrectly operated.

Register your guarantee online at: www.getbluelab.com

Or fill out the form below and post, email or fax to:

Bluelab Corporation Limited

8 Whiore Avenue, Tauriko Industrial Park, Tauranga 3110, New Zealand

Fax: +64 7 578 0847 Email: support@getbluelab.com

Product details	
Product name	
Serial number	
Date purchased	
Purchaser details	
Purchaser's name	
Address	
City	
Country	
Email (optional)	
Purchased from (De	alers details)
Purchased from	
Address	
City	
Country	
Phone number (optional)	



Bluelab Probe Care Kits

The instrument is only as accurate as the probe is clean!

Probe cleaning is one of the most important parts of owning and operating any Bluelab meter, monitor or controller. If the probe is contaminated (dirty) it affects the accuracy of the reading displayed.

The probe surface is where the instrument takes the reading of the solution. The information is sent back from the probe to the electronic brain of the instrument. A calculation is then done in the instrument's brain or micro computer and a reading is displayed. If the information sent back from the probe is inaccurate due to probe surface contamination then the reading will be inaccurate. Cleaning the probes is a very easy task and will prolong the life of the probes.





Bluelab Probe Care Kit - pH contents:

- Cleaning instructions inside box lid
- > 500ml pH4 and pH7 Calibration solutions
- Decanter vessels
- Bluelab pH Probe Cleaner
- > Toothbrush (probe cleaning instrument)

Bluelab Probe Care Kit - Conductivity contents:

- Cleaning instructions inside box lid
- 500ml 2.77EC conductivity standard solution
- Decanter vessel
- Bluelab Conductivity Probe Cleaner
- Bluelab Chamois (probe cleaning instrument)





If you need assistance or advice - we're here to help you. Phone: +64 7 578 0849 Fax: +64 7 578 0847

Email: support@getbluelab.com



Looking for specifications or technical advice? Visit us online @ www.getbluelab.com



Bluelab Corporation Limited 8 Whiore Avenue, Tauriko Industrial Park Tauranga 3110, New Zealand



Instruction Manual English 620305_V01_260811
© Copyright 2011, all rights reserved, Bluelab Corporation Limited