




Maintenance

Every 3 months check the external grid (C) positioned on top of the glass of the condenser (A) or when you notice the product decreases its effectiveness, it means it is necessary to clean the condenser or to replace it.



- Turn off the appliance removing the plug from the wall socket and removing also the connector from the product.
- Open the black plastic cover pushing gently and then rotating it on the side as shown in figures A/B.
- Remove the external grid (C) from the glass (A); if the operation is difficult, rotate the metal grid around the glass – Fig. C.
- Clean the glass with a moist cloth.
- WARNING:** Do not use detergents, soaps or similar.
- Wash the net outside (C) under running hot water and dry carefully with a dry cloth.
- Check whether the condenser shows any cracks or damages; if so, replace it.
- Generally, condenser replacement must be done after 12-18 months.
- Reposition the metal grid on the glass in the same position of the inner grid.
- WARNING:** leave a minimum distance of 2-3 mm from the bottom of the glass – Fig. E/F.
- Clean externally the appliance with a soft cloth and remove dust from the black cover on top of the air purifier.
- Close the cover of the device until the coupling (you hear a CLACK) – Fig. G/H.
- Plug the cable to the device and the wall socket.
- Verify the functioning (the internal led has to be switched on and you smell a light perfume).



Operating modes

The device has to work continuously. Unplug from the electrical socket and contact a specialized dealer if:

- The power cable is damaged.
- The plug is damaged or deteriorated.
- Water or other liquid has been spilled over the product.

In case of failure:

- Control the condenser slot and remove any dust or particulate set down in the black plastic cover grid.
- Clean the condenser and control its conditions. If the glass or the internal grid is whitish the condenser has to be replaced by a new spare part. If there is oxide on the external grid means that the condenser didn't receive the proper maintenance and if the oxide deposit is relevant this compromise the correct functioning of the product.
- Control the power cable.

After having applied the above actions, if the problem persists, please contact an authorized dealer or contact us at the following: <http://biioxigen.com>

Warranty terms and conditions

The Writing Party guarantees the repair of the systems it manufactured and distributed on the national territory, should the systems be found to be faulty in their materials or manufacture in the conditions listed below:

- The Warranty starts on the date of purchase and lasts for 24 months.
- The Warranty does not cover the breakage of the ionizing tube glass.
- Non-compliance with the use and maintenance instructions listed in the Manual enclosed with the equipment, makes the Warranty null and void.
- The Purchaser is entitled to 24 months' Warranty only if the Warranty Certificate has been filled in correctly and sent within 10 days from the date of purchase to:

Skil Group S.r.l.

+39 0415831151. info@biioxigen.com

Via Lombardia, 2 - 37044- Cologno Veneta (VR) ITALY

- The Warranty is valid only if the unit has been bought from an authorized dealer.
- The Warranty covers the free repair or replacement of the components that might be found to be faulty at origin and does never cover the replacement of the whole unit.
- The repairs under Warranty are carried out at the dealer's, if the repair takes place at the purchaser's, the latter needs to pay the repairer's fee.

- The units found to be damaged because of the reasons listed below are not covered by the Warranty: replacement of components or accessories with others not explicitly approved by the Writing Party, work carried out by unauthorized or untrained staff, non-compliance with the regulations regarding environmental conditions, negligence, lightning, floods, fires, acts of war, uprisings. Malfunctioning due to incorrect installation is not covered.
- The Warranty does not cover the units where the serial number is illegible, missing or altered.
- To take advantage of this Warranty, the Purchaser must take the faulty unit, together with a proof of purchase, to the dealer who sold it.
- All transport costs and risks are the Purchaser's responsibility.
- The carrying out of one or more repairs does not extend the expiry date of the Warranty.
- The responsibility of the Writing Party for any damage, both direct and indirect, to property or injury to people caused by any faults or consequences of the use or non-use of the units is excluded.
- The User authorizes the Writing Party and its Technical Service to file and deal with the User's personal details.

I unreservedly accept the above clauses, in particular clauses 1,2,3,4,5,6,7,8,9,10,11,12

Purchaser's signature: _____

Date: _____

Dealer's stamp: _____