# **Specification of Wood PLA**

#### ①Background

In the actual market, customers need to print some handicrafts having solid wood effects.

### **2Main Ingredients**

PLA, Toughener, wood Powder.

#### **③Features**

- Close to burlywood color.
- Having wood-like texture, wood fiber.

#### **4** Application and Target Audience

- Printing the woodwork that can be carved.
- Hobbyists of wood-like crafts.

#### **⑤PLA Filament Technical Specification**

• Filament Diameter: 1.75mm

• Tolerance: ±0.03mm

• Printing Temperature: 190°C-220°C

Heated Bed Temperature: 55-70°C

Printing Speed: 30 - 60mm/s

# **6**Shortcomings

- The ingredients contain woody fiber, so prints have web-like strings (stringing) issues.
- High temperature printing cause filament to be carbonized. The recommended printing temperature is ≤225°C.

# **⑦Relevant Parameters of Recommended Machine Types**

Relevant Parameters of Recommended Machine Types		
Туре	Extruder Type/Heated Bed Type	Parameter
Creality Ender 3	Bowden/Flexible Bed Sticker	Printing Temperature: 190-205℃
		Heated Bed Temperature: 55-65°C
		Printing Speed: 30-45mm/s
		Retracting Length: 2-4mm
		Retracting Speed: 60-100mm/s
Creality CR-10	Bowden/Glass Bed	Printing Temperature: 190-205°C
		Heated Bed Temperature: 65-70°C
		Printing Speed: 30-45mm/s
		Retracting Length: 2-5mm
		Retracting Speed: 80-110mm/s
Anycubic Mega-S	Bowden/ Microporous Coating Glass Bed	Printing Temperature: 190-205℃
		Heated Bed Temperature: 60-70°C
		Printing Speed: 30-45mm/s
		Retracting Length: 2-4mm
		Retracting Speed: 70-100mm/s
Prusa i3	Direct Drive Extruder/PEI Bed Sticker	Printing Temperature: 190-220℃
		Heated Bed Temperature: 55-70°C
		Printing Speed: 30-45mm/s
		Retracting Length: 0.8mm
		Retracting Speed: 30-40mm/s
Eryone Thinker S	Bowden/PEI Bed Sticker	Printing Temperature: 190-205℃
		Heated Bed Temperature: 55-70°C
		Printing Speed: 30-45mm/s
		Retracting Length: 4mm
		Retracting Speed: 90-110mm/s
Eryone Thinker SE	Bowden/Glass Bed	Printing Temperature: 190-205℃
		Heated Bed Temperature: 65-70°C
		Printing Speed: 30-45mm/s
		Retracting Length: 4mm
		Retracting Speed: 80-110mm/s
Eryone Thinker ER-20	Bowden/Silk-Screen Glass Bed	Printing Temperature: 190-205℃
		Heated Bed Temperature: 60-70°C
		Printing Speed: 30-45mm/s
		Retracting Length: 2-5mm
		Retracting Speed: 80-110mm/s



#### ®FAQ

- 1. Q:How do I solve nozzle wear?
- A: Woody PLA contains wood powder and wood fiber. Long-term use will easily cause wear to nozzles with lower hardness such as brass nozzles, which will affect printing. It is recommended to use nozzles with higher hardness.
- 2.Q: How do I troubleshoot the blockage caused by high-temperature printing?
  - A: Woody PLA contains wood powder. When the printing temperature exceeds 225°C, the PLA is likely to be carbonized and causes blockage. It is recommended to print at a low temperature of 190-210°C.
- 3.Q: Why my filament tangles? How can I solve it?
  - A: The tangle of filament isn' t caused by the disordered or the imperfect winding. According to the production technology of filament, the filament winds back and forth (from left to right and then from right to left). Normally, there is no overline tangle. A common cause of tangle is that the filament end is not fixed to the holes of spool. Overline tangle or the changed winding direction make filament tangle. So customers need to fix the filament end to the proper holes of the spool.
- 4.Q: Can PLA be used to print tableware?
  - A: Not recommended. Although PLA is degradable, food-grade raw material, the PLA with toughener is non-food grade.

    If you really want to print a set of tableware, transparent PLA is suggested.
- 5.Q: The nozzle is clogged by PLA, and how can I solve it?
- A: Inconstant filament diameter, the lower nozzle temperature and frequent replacement with different kinds of filaments will lead to this problem. So, before you get started, clean the nozzle and turn up the temperature to a proper value.
- 6.Q: My prints have web-like strings (stringing) issues. How can I troubleshoot it?
- A: Too high temperature makes the PLA filament melt and flow so fast. Please turn the temperature down to a proper value.
  - The retracting parameters are improper, so adjust the retracting length and speed.
- 7.Q: There are too much melted filament around the nozzle. What should I do?
- A: This problem can be attributed to over-high temperature, low printing speed, and in the slice software, the nozzle diameter doesn' t match with the extrusion output.
- 8.Q: The PLA filament was perfect when I opened the package. After several times of intermittent printing, my PLA filament snaps by accident during printing. Why?
  - A: Normally, the PLA filament in the printing process will not snap by themselves. However, after being affected by moisture, the degradable material PLA will be more brittle and easier to break, so you should pay attention to dampproof.
- 9.Q: The surface of my print isn't very smooth, and the extruded filament has inconstant diameters. Why?
- A: The printing temperature is too high or too low. The temperature doesn't match well with the printing speed. You need to adjust the printing speed or temperature.
- 10.Q: Why my PLA-printed objects don't stick to the heated bed? How do I solve?
  - A: The distance between the nozzle and the bed is too far. Make sure your heated bed is leveled and it's clean. Then judge if the printing temperature and heated bed temperature are too low, and our customers should adjust them to correct ranges.