WARRANTY

Thank you for purchasing the Qware Play & Charge Kit The product has warranty for two years. Our customer service will reply to you as soon as possible.

For questions and information: qware.nl

Model: QW XBS-7010

Distributed by: Pirox International B.V. www.qware.nl 6, 3011 TA Rotterdam The Netherlands

Specifications are subject to change without prior notice. Made in China











PLAY & CHARGE KIT





PLAY & CHARGE KIT

PLAY & CHARGE KIT

SPECIFICATIONS

Cabl	e length:	3 meter USB-A to USB-C cable
Battery capacity:		1200 mAh
Compatible with Xbox [™] Series X/S controller		

Product description:

- 1200 mAh rechargeable battery
- Easy to charge your Xbox[™] controller
- · Easy to attach and remove at any time
- Includes 3m USB-A to USB-C cable for simultaneous charging and playing


Content:

- 1x 1200 mAh battery
- 1x 3m USB-A to USB-C cable

PLAY & CHARGE KIT

1. PRODUCT INTRODUCTION:

- Rechargeable battery for Xbox[™] Series X/S controller.
- With 1x 1200mA battery pack:
 It can be installed in Xbox™ Series X/S controller and supply power.
- With one 3M Type C charging Cable:
 It can be used to charge the Qware battery.



PLAY & CHARGE KIT

2. PRODUCT FEATURES:

Support: made for Xbox[™] Series X/S controller

Input voltage: DC 5VBattery pack capacity: 1200mAh


• Accessories: 1x battery pack, 1x 3M charging cable


(3)

PLAY & CHARGE KIT

3. USING INTRODUCTION:

- Charge the battery pack directly.
- Connect the USB cable to the device or adapter with standard DC 5V USB port.
- Then connect the Type C port to the micro port of battery pack to charge the battery.





PLAY & CHARGE KIT

ATTENTION:

- The product should be used with stable standard DC 5V voltage, when it is charging one controller.
- When the product is damaged, please stop using it and send it to the professional to repair, do not disassemble it by yourself.
- If the product is filled with water, please air-dry it. Do not expose it in the sun.
- Do not scrub it with chemical reagent.
- Do not scratch it with sharp objects.