


## Installation steps [ Dashboard ]

Note: Please watch your hand during operation or use it.

**Step 1:** Put the ball joint into the nut and tighten it into the bolt of the holder.




**Step 2:** Fix the base of the suction cup holder at the appropriate position, and press the vacuum switch.




**Step 3:** Turn the knob on the front of support arm clockwise to adjust the height of the support rod.



**Step 4:** Turn the knob below the support arm forward to adjust it within 180 degrees.



**Step 5:** Press the two buttons below the clamping arm to open the clamping arm, put the phone into the holder, and then press the phone screen to lock it tightly.



## Warranty Card

Model: \_\_\_\_\_

Purchase Date: \_\_\_\_\_

Distributor: \_\_\_\_\_

Invoice Date: \_\_\_\_\_

Tel.: \_\_\_\_\_

Customer Name: \_\_\_\_\_

Zip code: \_\_\_\_\_

### After-sales service instructions

Dear users, thank you very much for using our products, in order to protect your rights and interests, it is clear that distribution agents and companies should bear the responsibility of product maintenance, replacement and returns. Please read the following items:

1. Product warranty card, necessary credential, which can provide after-sales service for free during the warranty period.
2. According to the principle of "who sells, who is responsible for the Three Guarantees", you can contact the distributor by provide with the warranty/product guarantee card. If the product cause quality problem, the distributor will service to the customer, while our company give supports to the distributor.
3. The company undertakes that if there is any quality problem within 7 days from the date of sale (the date is valid, the date of the bill shall prevail), the customer can choose to return the product for replacement and provide maintenance service for you. Or if it occurs quality problems beyond warranty period, we can provide lifetime maintenance service for you (each after-sales service sites only charge fees for component materials), please fill in the warranty (product guarantee card) with distributor when purchasing.
4. Warranty exceptions:
  - ① Exceed the Warranty service time
  - ② Damage caused by using, maintaining, keeping it not accordance to the instructions
  - ③ Damage caused by dismantling by the others who are not within the warranty scope
  - ④ No warranty
  - ⑤ (The guarantees card) the contents are not in equal to the physical product or it's altered
  - ⑥ Caused by force majeure
5. JOYROOM reserved the right of final interpretation of the above events.