

FATBIKE AMSTERDAM USER MANUAL - Niet hetzelfde als meegeleverd.

Globale montage instructie

How Easy It Is to Assemble Your OUXI V8 E-Bike

In order to ship the V8 e-Bike as efficiently as possible, components such as the front wheel and handlebars are partially disassembled before crating. Since these removed parts have a direct bearing on a vehicle's reliability and safety.

** The following assembly steps are only a general guide to assemble your V8 electric bike. We recommend you consult a certified, reputable bike mechanic to assist in the repair or replacing parts of your V8 bike.*

Let's Get Started

Before we officially start putting the V8 ebike together, make sure the box come in complete and un-damaged. OUXI provide all the bike tools and accessories needed to assemble the V8 bike for immediate riding.



What's in the box? - OUXI V8

V8 Electric Bike	Handlebar
Manual(s)	Handlebar holder
Disc Brake	Charger (54.6V 2A)
Front Wheel Axis	Pedals (marked left & right)
Bike Pump	Battery Keys (two, identical with number)
Front Fender	Assembly Tool kit (Allen wrench M3 – M6, Wrench 12-15, Scket wrench 8-10)
Front Wheel	

Please recycle packaging materials especially cardboard and foam (all #6 EPS foam).

How To Assemble Your V8 fatbike?

V8 electric bike assembly includes just a few super easy steps. It always helpful to find and read the owner's manual.

#1 Insert Front Wheel

Install disc brake on the front wheel; Insert the skewer through the front wheel axle from the side of brake disc, secure it with the 12-14 wrenches.

Note: 1. Place small parts on the axle according to the sequence in picture; 2. Inflate tires to recommended PSI. (Marked on the tire).

#2 Install Pedals & Fender

Insert the pedal (L for Left; R for Right) into its position, and tighten them with the 13-15 wrench; Install front fender with M5 Allen wrench and socket wrench to secure it.



#3 Attach Handlebar

Loose the trim cover with M5 Allen wrench, install the handle holder, there should be no gaps or shakes before really attaching the handlebar. Secure your handlebar and adjust the handlebar & fork to fit your riding position.

Go Ride!

Press and hold the M button on the controller until the display appears and you're ready to hit the road!

If you're still feeling out of your depth or like you may physically need a hand, contact a local bike shop or email to support@ouxibike.com.

Advice Before Test Riding OUXI V8 Bike

1. Check all control cables, throttle cable must not binding in any steering position.
2. Fully charge your battery before the first ride, it usually takes 5-7 hours to fully charge your V8 electric bicycle.
3. Adjust the brake caliper slightly if you feel the disc brake rub on the rotor.
4. Make sure V8 bike tires are inflated and verify the disc brakes are working properly, adequate, smooth stopping power, no drag.
5. Put on your helmet and you're ready to ride!