


### thinkplus Live Pods XT80 真无线蓝牙耳机



#### 使用说明

使用前请阅读使用说明



#### 产品规格

产品规格  
有效距离: ≥ 10m  
喇叭直径: φ 10mm  
喇叭功率: 5mW\*2  
阻抗: 32Ω  
麦克风灵敏度: 42dB ± 3dB  
信噪比: ≥ 90dB  
失真度: ≤ 3%  
频率响应: 20Hz-20KHz  
播放时长: 约6小时  
耳机电池容量: 55mAh  
充电仓电池容量: 500mAh  
耳机充电时长: 约1.5小时  
充电仓充电时长: 约1.5小时  
(所有技术信息以实际性能为准)

#### 物品清单

- 蓝牙耳机 x 2
- 充电线 x 1
- 充电盒 x 1
- 说明书 x 1
- 耳帽 x 6

#### 产品注意事项

(1) 除说明书有特殊标示的操作方式以外, 请勿尝试拆卸或更换产品内的任何零件。  
(2) 本产品含内置可充电电池, 禁止撞击、挤压、刺破、短路电池, 若出现温度过高、变形、鼓胀、漏液等异常现象, 请停止使用, 请勿置电池于明火、阳光曝晒、加热器、火炉等高温以及高压环境中, 电池浸水后禁止使用。耳机使用后, 应将耳罩放在潮湿、充满灰尘、油烟、蒸气、阳光直射等高温高压等环境中, 以免造成耳机及电池损坏。电池可充放电次数有限, 最终会老化, 电池使用异常时可更换新电池, 但切勿自行更换电池, 如果电池更换不当会有爆炸危险, 只能通过售后服务商更换同等类型或者等效类型的电池使用。  
(3) 产品使用报废后, 应将产品置入中、废旧处理应严格按照垃圾分类进行处理。请正确使用的使用此安全, 以免造成一定的伤害和环境破坏。  
(4) 在耳机使用过程中, 由于近距离、中间有障碍物或者其他无线电信号、蓝牙信号、WiFi信号等一系列的干扰的情况下, 耳机在使用时听音乐、看视频、玩游戏等情况下, 会出现偶尔的卡顿、语音不同步或者断连的情况, 如出现此情况请重新连接耳机或者远离干扰物。  
(5) 充电时充电器请使输出电压为直流DC 5V/1A的充电器, 必须选择正规生产厂家获得CCC安全认证的充电设备, 请勿使用快充充电器, 以免造成电池负载过大, 而产生电池损坏。连续充电时间请勿超过规定的充电时间, 充电时请勿使用, 以免造成损坏。

#### 安全与有效使用指南

注意: 请在使用蓝牙耳机前首先阅读此信息。  
用户如果未经许可而对此蓝牙耳机进行改动或改装, 将丧失继续享有该设备所含服务的权利。  
①电磁干扰:  
电子设备: 为避免电磁干扰或配置不兼容的影响, 请在标有明确指示的场所中按照规定关闭您的蓝牙耳机。

#### 产品操作说明

1. 开机  
方式一: 打开充电仓盖子, 耳机自动开机配对。  
方式二: 耳机关机的状态下 (在充电仓外), 长按左右耳机多功能按键约2秒钟, 耳机开机。  
2. 关机  
方式一: 将开机状态下的耳机直接放入充电仓并关闭充电仓盖子, 耳机自动关机并进入充电模式。  
方式二: 长按处于开机状态下的耳机多功能按键约5秒钟, 耳机关机。  
注: 当耳机开机后, 3分钟内未与相应蓝牙设备进行配对连接, 便会自动关机; 超出信号有效连接距离, 未与相应蓝牙设备连接, 3分钟后, 耳机自动关机。  
3. TWS配对  
a. 左右耳机无配对记录的情况下, 左右耳机开机后, 自动进行配对。  
b. 左右耳机有配对记录的情况下, 开机自动回连。  
4. 左右耳自动切换  
a. 耳机使用过程中, 把左 (右) 耳放入充电仓充电, 会自动切换到右 (左) 耳播放 (并继续保持切换的音乐状态)。  
b. 耳机使用过程中, 把左 (右) 放入充电仓充电, 不会影响右 (左) 耳的正常工作。

#### 产品操作说明

c. TWS连接后任意单耳使用过程中, 取出另一耳机可自动TWS连接, 左耳或右耳继续当前工作状态。  
d. 单独开启左耳或右耳, 都可回连手机。  
5. 与蓝牙设备进行配对连接  
打开准备好的蓝牙设备的蓝牙设置选项, 进入选项, 找到耳机的蓝牙配对名“联想 thinkplus XT80”, 点击配对名进行配对。  
6. 播放音乐  
上一曲: 连续单击右耳机多功能按键两次  
下一曲: 连续单击左耳机多功能按键两次  
音量加: 单击任意耳机DMH机械按键一次  
音量减: 单击任意耳机OP机械按键一次  
7. 暂停/播放: 短按任意耳机多功能按键一次  
8. 电话免提 (双耳配对操作)  
来电时, 接听: 单击任意耳机多功能按键一次  
来电时, 拒接: 长按任意耳机多功能按键2秒钟  
结束通话挂断: 在接通电话状态下, 单击任意耳机多功能按键一次  
9. 电话免提 (单耳配对操作)  
来电时, 接听: 单击耳机多功能按键一次  
来电时, 拒接: 长按耳机多功能按键2秒钟  
结束通话挂断: 单击耳机多功能按键一次  
10. 激活语音助手  
激活语音助手: 长按任意耳机多功能按键2秒钟, 可激活智能语音功能。  
游戏模式切换: 连续单击任意耳机多功能按键四次, 可切换游戏模式和音乐模式。

#### 产品操作说明

10. 指示灯显示  
耳机开机: (左) 右耳机指示灯呈白绿灯交替闪烁。  
耳机关机: (左) 右耳机指示灯呈白绿灯快闪3次后熄灭。  
对耳组队成功: 左 (右) 耳机指示灯呈白绿灯交替闪烁。(右) 左耳机指示灯熄灭。  
蓝牙耳机配对成功: (左) 右耳机指示灯熄灭。  
蓝牙耳机断连: 左 (右) 耳机指示灯呈白绿灯。  
充电仓给耳机充电: 充电仓在给耳机充电过程中, 耳机指示灯呈白灯常亮; 打开数显屏开关, 显示充电电量, 电池条显示充电状态, 当充满电后, 耳机指示灯熄灭, 充电仓数显屏相关无显示。  
充电仓充电: 充电器给充电仓充电过程中, 充电仓数显屏显示实时充电电量并以个位数值闪烁, 当充满电后充电电量显示为100%。



#### 产品中有有害物质名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。  
○: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以内。  
×: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。  
表中标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。  
印刷电路板组件: 包括印刷电路板及其零部件、电子元器件等, 根据产品型号不同, 您所购买的产品可能不会含有以上所有部件



在中华人民共和国境内销售的电子电气产品必须标识此标志, 标志内的数字代表在正常的使用状态下的产品的环保使用期限。


#### 保修声明

免责声明  
本使用手册没有任何形式的担保、立场表达或其他声明, 本使用手册所提到的产品、规格及信息仅供参考, 内容亦会随时更新于网页, 恕不另行通知。  
保修声明:  
就本文件附随的产品做如下保证: 如产品在您购买日起十二 (12) 个月 (“保修期”) 内, 在正常使用情况下因质量问题发生损坏, 能修理的, 免费修理; 经厂家确认无法修理的, 免费更换; 修理或更换后的产品, 在剩余保修期 (最短不少于30天) 内继续享有保修。购买日以销售发票日期为准; 如无法确定购买日, 则保修期自产品生产之日起按十三 (13) 个月计算。  
如申请保修, 请先致电产品服务热线, 并按我们指示的方式执行。申请保修时, 您需要提供准确、完整和清晰填写的有效销售发票。  
以上保证不适用于下列情况:  
1. 超过三包有效期的;  
2. 涂改保修卡、产品编码与产品本体不符;  
3. 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;  
4. 因不可抗力 (如地震、战争、火灾等) 或意外导致的故障或损坏;  
5. 刮擦、塔扣因受力过大而损坏;  
6. 因承载过重造成的脱线或断裂;  
7. 任何因尖锐物体造成的损坏;  
8. 有烧痕或水浸迹象的产品;  
9. 因擅自拆改导致的损坏;  
10. 产品正常使用过程中发生的老化、褪色、磨损、破裂和其他损耗。

#### 保修声明

11. 如产品原有标识标签被更改或损毁, 本保证将失效。  
产品及随附材料的齐备和外观完好不属于保证范围, 您应在接收产品时当场检验并对任何不符提出异议。  
以上保证是我们就产品做出的全部保证, 且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权益。  
服务监督热线: 400-812-0102  
售后邮箱: frank@szesyan.cn  
“Lenovo”, “thinkplus” 是联想集团所属企业的商标, 提及的其他公司、产品和服务名称可能是其他公司的商标。  
版权所有 © 2023 联想集团所属企业及其许可方保留所有权利。  
此产品仅限中国大陆地区销售。

### thinkplus Live Pods XT80



#### USER MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY AND RETAIN FOR FUTURE USE



#### Product specifications

Product specifications  
Effective distance: ≥ 10m  
Horn diameter: φ 10mm  
Speaker power: 5mW \* 2  
Impedance: 32 Ω  
Microphone sensitivity: 42dB ± 3dB  
SNR: ≥ 90dB  
Distortion: ≤ 3%  
Frequency response: 20Hz-20KHz  
Playing time: about 6 hours  
Earphone battery capacity: 55mAh  
Battery capacity of charging chamber: 500mAh  
Headphone charging time: about 1.5 hours  
Charging time of charging chamber: about 1.5 hours  
(All technical data is subject to actual performance)

#### List of items

- Bluetooth headset x 2
- Charging line x 1
- Charging box x 1
- Instruction x 1
- Ear cap x 6

#### Product precautions

(1) Do not try to disassemble or replace the product except for the operation methods that are specially marked in the manual. Any parts inside.  
(2) This product contains a built-in rechargeable battery. It is forbidden to hit, squeeze, puncture, or short-circuit the battery. If the current temperature is too high, deformation, swelling, liquid leakage and other abnormal phenomena, please stop using it and do not place the battery in the In high-temperature and high-pressure environments such as open flames, sun exposure, heaters, stoves, etc., the battery should not be immersed in water. Stop use.

After using the headset, do not place the headset in damp, dust, oily smoke, steam. In high temperature and high pressure environments such as direct light, so as not to cause damage to the headset and battery. The battery can be charged and discharged for a limited number of times, and it will eventually age. When the battery is used abnormally, you can replace the battery with a new one. However, do not replace the battery by yourself. If the battery is incorrectly replaced, there is a danger of explosion, Battery usage.  
(3) After the product is scrapped, do not throw the product into the fire, and the waste treatment should be strictly in accordance with the garbage classification To process, Please use this product reasonably and correctly, so as not to cause certain harm and environmental damage.  
(4) During the use of the headset, due to long distances, obstacles in the middle, or other wireless In the case of a series of interference such as electrical signal, Bluetooth signal, WiFi signal, etc., when the earphone is in use, listening to music, watching video, playing games, etc., there will be occasional freezes, unsynchronized voice or disconnection, such as In this case, please reconnect the headset or stay away from the interference.  
(5) When charging the charger, please use a charging device with an output voltage of DC 5V/1A. You must choose charging equipment that has been certified by a regular manufacturer with CCC safety certification, and do not use fast charging Electrical appliances, so as not to cause too much battery load, and cause battery damage. The continuous charging time should not exceed the specified charging time, and do not use it during charging to avoid damage.

#### Guidelines for safe and effective use

Note: Please read this information before using the Bluetooth headset. If the user changes or modifies this Bluetooth headset without permission, he will lose the continued enjoyment. Have the right to the services included in the device.  
① Electromagnetic interference:  
Electronic equipment: To avoid the influence of electromagnetic interference or configuration incompatibility, please Turn off your

Bluetooth device in accordance with the regulations. Civil Aviation: After boarding, please turn off your Bluetooth headset according to the instructions of the flight attendant. It is strictly forbidden to use Bluetooth headsets in flight to avoid interference with the aircraft communication system.  
② Safety matters:  
Placement: It is recommended that you place the Bluetooth headset in a place where it will not be squeezed when not using it. Pressure may cause product damage or personal injury. Children: Don't let children play with Bluetooth headsets, some of the small parts are detachable and may be swallowed. Swallow and cause danger.

#### Product operation instructions

1. Power on:  
Method 1: open the cover of the charging compartment, and the headset will automatically start to pair.  
Method 2: when the headset is turned off (outside the charging compartment), long press the left and right headset multifunction buttons for about 2 seconds, and the headset is turned on.  
2. Power off:  
Method 1: Put the headset in the on state directly into the charging compartment and close the cover of the charging compartment. The headset will automatically shut down and enter the charging mode.  
Method 2: long press the left and right earphone multifunction keys in the power on state for about 5 seconds, and the earphone will be turned off.  
Note: when the headset is turned on, it will automatically turn off if it is not paired with the corresponding Bluetooth device for 3 minutes; Beyond the effective connection distance of the signal, not connected with the corresponding Bluetooth device, 3 minutes later, the headset will automatically turn off.  
3. TWS pairing:  
a. When there is no pairing record between the left and right earphones, the left and right earphones will be paired automatically

after they are turned on.  
b. When the left and right earphones have matching records, they will be automatically connected back when they are turned on.  
4. Automatic switch between left and right ears:  
a. In the process of using the headset, put the left (right) ear into the charging box to charge, and it will automatically switch to the right (left) ear to play (and continue to maintain the music state before switching).  
b. In the process of using the earphone, put the left (right) into the charging box for charging, which will not affect the normal operation of the right (left) ear.  
c. After TWS connection, when any one ear is in use, take out another headset to automatically connect TWS, and the left and right ears continue to work.  
d. Turn on the left or right ear separately to connect the mobile phone back.  
5. Pairing with Bluetooth device:  
Open the Bluetooth setting option of the Bluetooth device to be paired, enter the option, find the Bluetooth pairing name of the headset "Lenovo thinkplus XT80", and click the pairing name to pair.  
6. Play music:  
Previous song: click the right earphone multifunction button twice  
Next song: click the multi-function button of the left earphone twice in succession  
Volume plus: click any headset DM mechanical key once  
Volume reduction: click any earphone OP mechanical button once  
Pause / play: briefly press any earphone multifunction button once  
7. Hands free telephone (paired operation of two earphones):  
Answer an incoming call: click any headset multifunction button once  
In case of incoming call, reject: long press any earphone multifunction button for 2 seconds  
End the call and hang up: when the call is connected, click any headset multifunction button once

8. Hands free (single headset operation):  
Answer an incoming call: click the headset multifunction button once  
Reject the incoming call: long press the multi-function button of the headset for 2 seconds  
End the call and hang up: click the headset multifunction button once  
9. Activate voice assistant:  
Voice assistant activation: Press and hold any headset multi-function button for 2 seconds to activate the intelligent voice function.  
Game mode switch: click any headset multi-function button four times in a row to switch between game mode and music mode.  
10. Indicator light display:  
Headset on: (left) The right headset indicator light is flashing alternately white and green.  
Headset off: (left) right headset indicator light flashes white and green 3 times and then goes off.  
Pair of ear teaming success: (left) the left (right) headset light is alternately flashing white and green, (right) the left headset light is off, Disconnected pairing: (left) right headset indicator light flashes white and green alternately.  
Bluetooth pairing successful: (left) right headset indicator light off, Bluetooth disconnection: (left) right headset indicator light is white and green, (right) left ear indicator light is off.  
Charging bin to the headset charging: charging bin in the process of charging the headset, headset indicator light is always on white; open the digital display screen switch, display charging power, battery strip shows charging status, when fully charged, headset indicator light off, charging bin digital display screen off / no display.  
Charging the charging compartment: during charging of the charger to the charging compartment, the charging compartment digital display shows real-time charging, the power level and flashes with a single-digit value, when fully charged the charging compartment power level is shown as 100%.

