
### Package Contains

HUAWEI Wireless Charger x 1 USB Type-C data cable x 1 Charging adapter (model: HW100400E00, HW100400B00, HW100400U00, HW-100400A00, HW-100400A00) x 1 Quick start guide x 1

# Charging Your Wireless Phone

- 1. Connect the charging adapter to a power outlet and the data cable.
- Connect the data cable to the wireless charger through the USB Type-C port.
- Place the rechargeable area of the phone onto the center surface of the wireless charger. Charging will begin on contact. (To locate the rechargeable area of the phone, please refer to the phone's user manual)



When charging, please position the wireless charger with the logo facing upwards.

- The wireless charger comes equipped with multiple security protection features. If you encounter an error during charging, check and fix any issues that your phone may be experiencing, and then place your phone back on the wireless charger.
- For best charging performance, it is recommended that you use a Huawei-approved charger.

## Fast Wireless Charging

To begin charging, place your Huawei phone that supports fast wireless charging onto the wireless charger.

For more details, please refer to the phone's user manual.



- It is recommended that you use the standard charging adapter (model: HW100400E00, HW100400B00, HW100400U00, HW-100400A00) that came with the device.
- Make sure the center of the phone is aligned over the center of the wireless charger. If the phone is not correctly placed, it may not charge properly.
- If the phone uses a protective case, remove the case and place the phone correctly onto the wireless charger, as protective cases or metal contents contained in protective cases may cause the phone to not charge properly or induce additional heat.
- To keep the wireless charger in good condition, avoid using it inside a vehicle.
- Avoid placing your phone with bank cards or transportation cards while charging, as the card chips may affect the charging mechanism.

### Indicator Descriptions

Color	Description
The indicator is off.	The wireless charger is not connected to a power supply or the phone has been removed from the wireless charger.
The indicator blinks	The wireless charger is connected to a power
white once.	supply.
The indicator stays	The phone is being charged or is fully charged.

steady white.	
The indicator blinks	An error has occurred.
white quickly.	

### Safety Information

Before you use the device, read the following precautions carefully to ensure optimal product performance and to avoid danger or violation of laws and regulations.

- In clinics and hospitals where the use of wireless devices is prohibited, please comply with the regulations and power off your device.
- Some wireless devices may interfere with implantable medical devices and other medical equipment, such as pacemakers, cochlear implants, and hearing aids. Consult the manufacturer of your medical equipment for more information.
- · When using the device, keep it at least 30 cm away from medical devices.
- Keep the device dry. Avoid using the device in dusty, damp, or dirty environments, as such environments may damage the internal circuitry.
- Do not use the device during thunderstorms, as thunderstorms may cause equipment malfunction or a shock hazard.
- Please only use the device within its approved operating range of -10°C to +45°C, and only allow it to be exposed to temperatures within its approved storage range of -40°C to +70°C. Extreme heat or cold may damage the device.
- If the charging adapter needs to be replaced, the output of the adapter must match the specifications of the wireless charger, and must meet the requirements of Clause 2.5 in GB4943.1.
- If the device needs to be connected to a USB port, ensure that the USB port is USB-IF certified, and that it complies with the USB-IF standards.
- Keep the device away from excessive heat sources and direct sunlight. Do not place it on or in heating devices, such as microwave ovens, stoves, or radiators.
- Do not attempt to disassemble or remanufacture the device, insert foreign
  objects into it, or immerse or expose it to water or other liquids. Doing so
  may lead to fire, or other hazards.
- Dispose of the device in accordance with local regulations. Do not

dispose of the device in normal household waste. Please respect local laws on the disposal of electronic products and their accessories and support recycling efforts.

- To prevent accidental swallowing and choking, keep the device out of reach of children and pets.
- The device and its accessories may contain small components. Keep the device and its accessories out of the reach of children. Otherwise, children may damage the device and its accessories by mistake, or swallow the small components, which may result in hazards such as choking.
- Do not drop, squeeze, or pierce the device to avoid short-circuiting and overheating.
- Connecting the device to non-approved or incompatible power supplies, chargers, or batteries is not advised as this may cause fires.
- Do not wirelessly charge a device that does not meet the Qi standard, and avoid placing metal objects onto the surface of the wireless charger, as they may induce heat and cause equipment malfunction.
- To maintain good use, avoid using the data cable that came with the product for other devices.

### **Disposal and Recycling Information**



The crossed-out wheeled bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the

normal waste stream with household garbage. It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws.

Proper collection and recycling of your equipment helps ensure electrical and electronic equipment (EEE) waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment. For more information about where and how to drop off your EEE waste, please contact your local authorities, retailer or household waste disposal service or visit the website http://consumer.huawei.com/en/.

### Reduction of Hazardous Substances

This device and any electrical accessories are compliant with local applicable rules on the restriction of the use of certain hazardous substances in electrical and electronic equipment, such as EU REACH, ROHS and Batteries (where included) regulations, etc. For declarations of conformity about REACH and ROHS, please visit our web site http://consumer.huawei.com/certification

### EU Regulatory Conformance

#### **Body Worn Operation**

This device has been tested and meets applicable limits for radio frequency (RF) exposure.

The highest value reported to this device type when using in transportable exposure conditions is  $0.331 \,\mu\text{T}$  at 15 cm.

#### Statement

Hereby, Huawei Technologies Co., Ltd. declares that this device CP60 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

The most recent and valid version of the DoC (Declaration of Conformity) can be viewed at http://consumer.huawei.com/certification.

This device may be operated in all member states of the EU.

Observe national and local regulations where the device is used.

This device may be restricted for use, depending on the local network.

### Frequency Bands and Power

(a) Frequency bands 111-148 kHz.

(b) Maximum radio-frequency power transmitted in the frequency bands in which the radio equipment operates: The maximum power for all bands is less than the highest

limit value specified in the related Harmonized Standard.

The frequency bands and transmitting power (radiated and/or conducted) nominal limits applicable to this radio equipment are as follows: 29.90 dBµAm at 3 m.

### Accessories and Software Information

It is recommended that the following accessories should be used: Adapters: HW100400E00, HW100400B00, HW100400U00, HW-100400A00 The product software version is FW-88.66.2.10. Software updates will be released by the manufacturer to fix bugs or enhance functions after the product has been released. All software versions released by the manufacturer have been verified and are still compliant with the related rules. All RF parameters (for example, frequency range and output power) are not accessible to the user, and cannot be changed by the user. For the most recent information about accessories and software, please see

For the most recent information about accessories and software, please see the DoC (Declaration of Conformity) at

http://consumer.huawei.com/certification.

### FCC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

--Increase the separation between the equipment and receiver.

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications to this device not expressly approved

by Huawei Technologies Co., Ltd. for compliance could void the user's authority to operate the equipment.

# Legal statement

Copyright © Huawei Technologies Co., Ltd. 2018. All rights reserved. This document is for reference only. Nothing in this guide constitutes a warranty of any kind. express or implied

All pictures and illustrations in this guide, including but not limited to the product color, size, and display content, are for your reference only. The actual product may vary. Nothing in this guide constitutes a warranty of any kind, express or implied.

Please visit http://consumer.huawei.com/us/support/index.htm for recent updated hotline and email address in your country or region.

# Privacy Protection

To understand how we protect your personal information, please visit http://consumer.huawei.com/privacy-policy and read our privacy policy. For United States warranty card information, visit

http://consumer.huawei.com/us/support/warranty-policy/index.htm.