

## User Manual

External DVD Drive USB 3.0/Type-C

### Note

- Don't support the Mac OS format.
- Don't put it on unstable surfaces.
- Don't put the item by the strong magnetic objects.
- Keep the product steady on the desktop.
- The maximum readable capacity of the item is 8.5G.
- For Apple MacBook Type-C Interface, please eject disk before you connect.
- For devices, please connect the back USB port of the mainboard instead of front USB interface.
- Inside laser light source may be harmful to the eyes, please don't look directly at the light source.
- Don't put the item on the vulnerable squeeze place to ensure successfully normal user.

### Product Features

- No need to install the driver, plug & play.
- Standard Type-C port, support hot plug.
- Innovative design of the data cable.
- Could meet the needs of both CD/DVD.
- The external CD drive is suitable to connect desktop computer or laptop with USB3.0/Type-C interface.
- Compatible with Windows XP/2003/Vista/7/8.1/10, Linux, Mac OS X.
- Adopt pure copper mesh technology, low impedance and strong protection, which provide more stable data transmission.
- Support CD format: DVD+R/RW/+R/+RW/-R DL/DCA, CD-R/CD-RW/+RW, VCD.

### Instructions

- Step 1: Please connect to the USB port of the computer via a standard USB data cable. The computer display "lower right corner" should appear device icon.

Step 2: Click the "This PC" icon on the "My Computer", in "the mobile storage device" should display the drive icon.

Step 3: Click on this icon button, right click drive icon, please choose "pop-up", then it will read the disk.

### Possible Problems & Solutions


1. For the desktop computer, please plug the USB cable to the back port behind the computer host (Pic 2), rather than the front one (Pic 1).




2. When the input ports are not enough of your computer, you should connect the CD to the computer input port directly, don't use other device to connect, such as USB HUB (Pic 1 & Pic 2).



3. Note that CD Drive can not be used through the adapter in order to make sure of sufficient power supply.



4. If you are using Apple laptop, you must choose each cable-free transfer (Pic 1), not the ones with cables(Pic 2).



5. This product is equipped with USB 3.0 & Type-C interface. Both of them can be plug and play.

### Precautions

The external drive depends on whether the operating system of your computer have the function of deleting other device, otherwise you have to download the driver. Generally speaking, almost all of the older operating systems do not support the function + RW through direct installation or external connection.

So if the operating system of your computer has the drivers or has the ability to download drivers, the external CD/DVD can be used.

### Methods to Handle Exceptions

Please make sure your computer have downloaded CD/DVD driver before using the CD drive. If you are using Windows 10 or above system, please install the "Windows Play" in the "Device Manager".

Please connect the item to the direct USB port of your computer. If you connect it to a USB hub or extended card, it may not recognize the item, or can't read the CD/DVD.