

Perow electric lighter

- For lighting candles, BBQ, cigarettes, incense, gas stove, solid alcohol etc.

Features:

- Environmentally Friendly
- Rechargeable
- Convenient USB connection
- Low-Carbon electricity
- Long lifecycle
- More safety
- Smart charging circuit

Instructions:

- Charging through the USB cable by connecting to computers, cell phone chargers and any other chargers with the output voltage of $DV 3.7V \pm 0.5V$ and output current below 280MA.
- When charging, the battery indicator of the product will increase according to the increase of battery power, there are four indicators. When fully charged, all indicator will light.
- A charge can be filled within 2-3h. Be sure to disconnect the power immediately after fully charged. Overcharging will shorten battery life.
- The battery is rechargeable. Before the battery is fully discharged, immediately charging after use will extends battery life.
- When using, press and hold the power switch for three seconds till the indicator will light up. Then push up the ignition switch, if you need to use it again, refer to the previous steps.
- During the ignition, there will be noise of “zee, zee”, which is high-voltage power generation, please use carefully.

WARNING: KEEP OUT OF REACH OF CHILDREN. Failure to follow the instructions may result in burn injuries.

- Do not use a sharp object to pierce or burn this product.
- Do not touch the arc place as there is the risk of high temperature and voltage.
- Do not place the product into water or other liquids into moisture status, or it will cause a short circuit.
- Do not use this product on any charger other than the chargeable chargers mentioned above! This could cause explosion.
- Do not lit for more than 10 seconds, in order to avoid the high temperature to burn the skin and affect product life.
- Ignite lighter away from face, skin, clothing and other combustible substances.
- Be sure the flame has been fully extinguished after use.
- Never expose to temperature from sun or otherwise more than 50 °C (120F). Avoid prolonged sun exposure, especially in a glass case or in a car.
- Never puncture or put in fire. Do not place near flame or sparks.
- Do not leave the fully charged battery connected to a power source.