

# USER MANUAL



CYCLING  
LIGHTS



WARNING  
LIGHTS



MULTIPLE  
MODES



IPX6  
WATERPROOF



LONG  
RUNTIME



USB  
RECHARGEABLE



BATTERY  
INDICATOR



1 Rotate the silicone strap bracket interface counterclockwise/ clockwise to the buckle on the back of the bicycle light



2 Attach the silicone strap bracket back notch to the handlebar with one hand



3 Tighten the silicone strap and snap it into the appropriate hole



4 You could adjust the bike light to horizontal or vertical

## PACKAGE CONTENTS







Accessories	Count
Front Light - White	*1
Rear Light - Red	*1
Dual Wire Charging Cable	*1
Silicone Bracket Strap	*2
User Manual	*1



## SPECIFICATION

	Front Light - White	Rear Light - Red
LED Bulb Quantity	2 Main Lights + 19 Auxiliary Lights	2 Main Lights + 19 Auxiliary Lights
Lumen	300 LM + 100 LM	50 LM + 50 LM
Battery Life	4-58 Hrs	4-25 Hrs
Battery Capacity	1100 MAH	350 MAH
Charging Time	2.5 Hrs	1.5 Hrs
Lighting Modes	8 Modes	12 Modes
Weight	45 g	32 g
Dimension	50*40*30(mm)	
Material	PC	
Waterproof Level	IPX6	

## LIGHTING MODE OPTIONS

	<b>Front Light - White</b>
A - Main Lights	
B - Sublights	
	<b>Rear Light - Red</b>
A - Main Lights	
B - Sublights	
<p><b>Tips:</b></p> <ol style="list-style-type: none"> <li>1. The main lights and the auxiliary lights are controlled by 2 independent switches, which can be used together or separately. Provide more lighting modes for you to choose!</li> <li>2. There will be a green indicator on the independent switch to facilitate identification of which light is on, and when the power is below 20% will show a green blinking state.</li> </ol>	